

# AWK Series User Manual

---

Version 1.0, June 2024

[www.moxa.com/products](http://www.moxa.com/products)

**Models covered by this user manual:**

AWK-1161C Series  
AWK-1165C Series  
AWK-1161A Series  
AWK-1165A Series



© 2024 Moxa Inc. All rights reserved.

# AWK Series User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## Copyright Notice

© 2024 Moxa Inc. All rights reserved.

## Trademarks

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Technical Support Contact Information

[www.moxa.com/support](http://www.moxa.com/support)

# Table of Contents

<b>1. About This Manual</b>	<b>5</b>
Symbol Definition for Web Interface Configurations	5
About Note, Attention, and Warning	6
Configuration Reminders	7
A: About Mandatory Parameters	7
B: Preconfiguring Settings	7
<b>2. Getting Started</b>	<b>9</b>
Functional Design	9
LED Indicators	9
Event Indicators	10
Reset Button	10
First-time Installation and Configuration	10
Communication Testing	14
<b>3. Web Interface Configuration</b>	<b>16</b>
Function Introduction	16
Device Summary	17
Device Information	17
System Information	17
System Status	18
Security Status	18
System	18
System Management	19
Account Management	33
Management Interface	41
Time	48
Wi-Fi	52
Wireless Settings	52
Connection Management	70
Roaming (AWK-1161C, AWK-1165C Only)	77
Wi-Fi Security	78
Ports	80
Port Settings	80
Layer 2 Switching	82
VLAN	82
IP Configuration	88
General Settings	88
IPv6	89
IP Configuration Status	92
Network Service	92
DHCP Server	92
DHCPv6 Server	93
Routing and NAT	94
Routing	95
NAT (AWK-1161C, AWK-1165C Only)	98
Firewall	103
Layer 2 Policy	103
Layer 3 Policy	105
Certificate Management	107
Device Certificate	108
Server CA Certificate	109
Security	110
Device Security	110
Diagnostics	112
Security Status	113
System Status	114
Network Status	117
Event Logs and Notifications	120
Tools	130

Setup Wizard .....	138
Wi-Fi Basic .....	139
Wi-Fi Security .....	141
System .....	143
Maintenance and Tools .....	145
Language .....	145
Disable Auto Save .....	146
Locator .....	147
Reboot.....	149
Reset to Defaults.....	149
Renew Device Unique Key .....	151
Change Password .....	151
Log Out.....	153
<b>A. Supporting Information .....</b>	<b>154</b>
Device Recovery .....	154
<b>B. Accessing the Serial Consoles.....</b>	<b>156</b>
RS-232 Console Configuration (115200, None, 8, 1, VT100) .....	156
Configuration by Telnet and SSH Consoles .....	158
<b>C. Security Guidelines .....</b>	<b>160</b>
Installation .....	160
Physical Installation .....	160
Account Management.....	161
Vulnerable Protocols .....	161
Operation .....	161
Maintenance .....	162
Decommission.....	162
<b>D. Service Authority Table .....</b>	<b>163</b>

# 1. About This Manual

---

Thank you for purchasing a Moxa's AWK-1160A Series or AWK-1160C Series product, referred to as 'AWK Series' in this manual. Read this user's manual to learn how to connect your Moxa product with various interfaces and how to configure all settings and parameters via the user-friendly web interface. Note that the web interface screenshots shown in this manual use the AWK-1161A Series and AWK-1165C Series for reference. Since all AWK Series use the same firmware image, the screenshots will be identical for all models, with the exception of the model name.

Three methods can be used to connect to the Moxa's device, which all will be described in the next two chapters. See the following descriptions for each chapter's main functions.

## Chapter 2: Getting Started












In this chapter, we provide instructions on how to initialize the configuration on Moxa's product. We provide two interfaces to access the configuration settings: CLI (Command Line Interface) via the RS-232 console or SSH/Telnet interfaces, and web interface.




















## Chapter 3: Web Interface Configuration

In this chapter, we explain how to access the AWK Series various configuration, monitoring, and management functions. These functions can be accessed through a web browser, or through the command line console (CLI). In this manual, we describe how to configure the AWK Series functions via the web interface, which provides the most user-friendly way to configure a Moxa device. For more information on how to configure the AWK Series using the command line interface, refer to the AWK Series Command Line Interface User Manual.

## Symbol Definition for Web Interface Configurations

The Web Interface Configuration includes various symbols. For your convenience, refer to the following table for the meanings of the symbols.

Symbols	Meanings
	Add
	Read detailed information
	Clear all
	Column selection
	Refresh
	Enable/Disable Auto Save When Auto Save is disabled, users need to click this icon to save the configuration.
	Export
	Edit
	Perform a Wi-Fi site survey (Client mode only)
	Re-authentication
	Delete

Symbols	Meanings
	Panel View
	Expand
	Collapse
	Hint or additional information
	Settings
	Data comparison
	Menu icon
	Change mode
	Locator
	Reboot
	Reset to defaults
	Logout
	Increase
	Decrease
	Equal
	Menu
	Search
	Hide text that is typed into a text box (usually used when typing a password)
	Show text typed into a text box (usually used when checking a password)

## About Note, Attention, and Warning

Throughout the whole manual, you may see notes, attentions, and warnings. The definition of each type is explained below.

**Note:** This is used to provide additional information for a function, feature, or scenario. Here is an example:



### NOTE

Reset to Default button is disabled by default; users need to enable it in the web console if they want to use it.

**Attention:** This is used to notify readers of matters or situations that require extra attention to avoid possible issues. Here is an example:



### ATTENTION

When a different type of module has been inserted into the AWK Series, we suggest you configure the settings, or use reset-to-default.

**Warning:** This is used to notify readers of matters or situations that require extra attention to avoid serious harm to the user or the device. Here is an example:



## WARNING

There is a risk of explosion if the battery is replaced by an incorrect type.

# Configuration Reminders

In this section, several examples will be used to remind users when configuring the settings for Moxa's AWK Series.

## A: About Mandatory Parameters

The screenshot shows a web form titled "Create Static Route Entry". It contains several input fields and dropdown menus. The "Entry Status" dropdown is set to "Disabled". The "Name" field has a character count of "0 / 31". The "Destination" field is highlighted in red and labeled "Required". The "Netmask" dropdown is set to "24 (255.255.255.0)". The "Interface" dropdown is set to "WAN". At the bottom right, there are two buttons: "CANCEL" and "CREATE".

- The items with asterisks mean they are mandatory parameters that must be provided. In the figure above, the parameters for Entry Status, Destination, and Interface are required to be able to save or apply the configuration.
- If an item is marked in red means this item has been skipped. You need to fill in the parameters or you cannot apply or create the function.
- Some parameter values will be limited to a specific range. If the values exceed the range, it cannot be applied or created.
- Configuration input fields universally do not allow the following special characters: backslash (\), apostrophe ('), double quotes ("), backtick (`).

## B: Preconfiguring Settings

Some function settings can be configured while the function is disabled. These changes will take effect when the function is enabled, without having to reconfigure the settings again. For example, on the SNMP configuration page, users can configure the SNMP Account List settings while SNMP is disabled. When SNMP is enabled, the previously configured Account List settings will take effect.

## SNMP

SNMP

SNMP Account List

SNMP V1 and V2c are not secure. We recommend using SNMP V3.

SNMP Status \*

Disabled



APPLY




## 2. Getting Started

In this chapter, we provide an overview of the AWK Series, and explain how to log into the Moxa's AWK Series for the first time through the web-based interface.

### Functional Design

#### LED Indicators

The LEDs on the front and right panels of the AWK Series provide a quick and easy means of determining the current operational status and wireless settings.



The following table summarizes how to read the device's wireless settings from the LED displays.

LED	Color	State	Description
<b>Front Panel LED Indicators</b>			
<b>PWR</b>	Green	On	Power is being supplied from DC to the PWR socket.
		Off	Power is not being supplied from DC to the PWR socket.
<b>WLAN</b>	Green	On	Client/Client-Router/Slave has established a Wi-Fi connection to an AP/Master with a SNR value of 35 or higher.
		Blinking	Data is being transmitted over the wireless interface (2.4 GHz or 5 GHz).
	Amber	On	Client/Client-Router/Slave has established a Wi-Fi connection to an AP/Master with a SNR value of less than 35.
		Blinking	Data is being transmitted over the wireless interface (2.4 GHz or 5 GHz).
<b>SYSTEM</b>	Red	On	System initialization failure, configuration error, or system error.
	Green	On	System startup completed and is operating normally.
<b>LAN LED Indicators (integrated into the RJ45 Port)</b>			
<b>LAN1~5</b>	Green	On	Link established on the LAN port at 1000 Mbps.
		Blinking	Data is being transmitted at 1000 Mbps.
		Off	LAN port's 1000 Mbps link is inactive.

LED	Color	State	Description
	Amber	On	Link established on the LAN port at 10/100 Mbps.
		Blinking	Data is being transmitted at 10/100 Mbps.
		Off	The LAN port's 10/100 Mbps link is inactive.

## Event Indicators

The device LEDs are also used to indicate specific device events or issues. Refer to the following table for more details.

Applicable Models	AWK-1160C AWK-1160A	
	SYS	
LED	Red	Green
IP address conflict detected.	Blinks at 4 Hz	Off
Failed to get an IP from the DHCP server.	Blinks at 4 Hz	Off
ABC-02 is connected.	Off	Blinks at 4 Hz
Uploading/retrieving file(s) to/from ABC-02 (e.g., upgrading firmware, backup/restore configuration).	Off	Blinks at 4 Hz
Failed to upload/retrieve file(s) to/from ABC-02. Possible reasons are: The file does not exist, failed to copy the file, or the ABC-02 has insufficient space.	Blinks at 4 Hz	Off
The device is being located.	Off	Blinks at 4 Hz
The Reset button is being pressed for less than 5 seconds (system reboot).	Off	Blinks at 1 Hz
The Reset button is being pressed for 5 to 10 seconds (system factory reset).	Off	Blinks at 4 Hz
The Reset button is being pressed for longer than 10 seconds (abort reboot or reset).	Off	Solid on

## Reset Button

Depending on the AWK Series model, the Reset is located on the bottom panel of the device. You can reboot the AWK series or reset it to factory default settings by pressing the **RESET** button with a pointed object such as an unfolded paper clip.

- **System reboot:** Hold down the Reset button for under 5 seconds and then release. The SYS LED will blink at 1 Hz.
- **Reset to factory default:** Hold down the Reset button for over 5 seconds until the SYS LED starts blinking green. Release the button to reset the AWK Series to its factory default settings. The SYS LED will blink at 4 Hz.
- **Abort the action:** Hold the Reset button down for longer than 10 seconds and then release to abort the reset action. The SYS LED will stop blinking and turn solid.



### NOTE

The reset to default factory settings function of the reset button is disabled by default and must be enabled in the web console. Refer to the [Reset Button Active Duration](#) section for more detailed information.

## First-time Installation and Configuration

Before installing the AWK Series, make sure that all items in the Package Checklist listed in the Quick Installation Guide are in the box. You will need access to a notebook computer or PC equipped with an Ethernet port.



## NOTE

The images in the instructions below use the AWK-1161A Series interface for reference. The instructions are identical for all supported AWK models.

**Step 1: Select the power source.**

The AWK Series can be powered by a DC power input.

**Step 2: Connect the AWK Series to a notebook or PC.**

Since the AWK Series supports MDI/MDI-X auto-sensing, you can use either a straight-through or crossover cable to connect the AWK Series to the computer. The LED indicator on the AWK Series' LAN port will light up when a connection is established.

**Step 3: Set up the computer's IP address.**

Choose an IP address on the same subnet as the AWK Series. Since the AWK Series' default IP address is **192.168.127.253**, and the subnet mask is **255.255.255.0**, you should set the IP address of the computer to **192.168.127.xxx**.


**Step 4: Access the homepage of the AWK.**

Open your computer's web browser and type **https://192.168.127.253** in the address field to access the AWK's homepage. If successfully connected, the AWK's interface homepage will appear. Click **NEXT**.



**Step 5: Choose your country or region. (Not applicable to -US models)**

Select your country or region from the drop-down list and click **NEXT**.




**Step 6: Create a user account and password.**

There is no default user account and password. Enter the username, password, and email address for your user account and click **CREATE**.




**NOTE**

The username and password are case-sensitive.



The image shows the Moxa administrator account creation interface. At the top, the Moxa logo is displayed in white. Below it, the heading "Create your administrator account" is centered. The form includes four input fields: "Username \*" with a minimum of 4 characters and a 0/32 character count; "New Password \*" with a minimum of 8 characters and a 0/63 character count, accompanied by a visibility toggle icon; "Confirm Password \*" with a minimum of 8 characters and a 0/63 character count, also with a visibility toggle icon; and "Email". At the bottom of the form are two buttons: "BACK" and "CREATE". A progress indicator with three dots is visible, with the third dot being filled. The footer contains the copyright notice: "Copyright © 2023 Moxa, Inc. All Rights Reserved."

After creating your account, you will be automatically redirected to the login screen.



**Step 7:** Log in to the device.

Once the initialization message (in red font) has disappeared, enter your username and password and click **LOG IN**.



## Communication Testing

After installing the AWK Series you can run a sample test to make sure the AWK Series and the wireless connection are functioning normally. Two testing methods are described below. Use the first method if you are using only one AWK Series device as an AP and use the second method if you are using AWK Series devices as Client and AP.

### How to Test the AWK Series as an AP


#### ***AWK-1161A/AWK-1165A only***

If you are testing the AWK Series device as an AP, you will need a second notebook computer equipped with a WLAN card. Configure the WLAN card to connect to the AWK Series and change the IP address of the second notebook (Notebook B) so that it is on the same subnet as the first notebook (Notebook A), which is connected to the AWK Series.

After configuring the WLAN card, establish a wireless connection with the AWK Series and open a DOS window on Notebook B. At the prompt, type the following command:

**ping** <IP address of notebook A>


Press **Enter** to execute the command (see the figure below). A "Reply from IP address ..." response means the communication was successful. A "Request timed out." response means the communication failed. In this case, recheck the configuration to make sure the connections are correct.



## How to Test the AWK Series as a Client

### *AWK-1161C/AWK-1165C only*

If you are testing the AWK Series as a Client, you will need a second notebook computer (Notebook B) equipped with an Ethernet port as well as an AP connected to notebook A. Configure the AWK Series connected to notebook B for Client mode with the correct SSID and credentials matching the target AP.



After setting up the testing environment, open a DOS window on notebook B. At the prompt, type:

**ping** <IP address of notebook A>


and then press **Enter**. A "Reply from IP address ..." response means the communication was successful. A "Request timed out" response means the communication failed. In this case, recheck the configuration to make sure the connections are correct.

# 3. Web Interface Configuration

Moxa's AWK Series offers a user-friendly web interface for easy configuration. All functions of the Moxa's AWK Series can be configured via this web interface.

## Function Introduction

This section describes the web interface design, providing a basic visual concept for users to understand the main information or configuration menu for the web interface pages.



1. **Login Name:** This shows the name of the user that is currently logged in.
2. **Search Bar:** Type the name of the function you want to search for in the function menu tree.
3. **Function Menu:** All functions of the AWK Series are shown here. Click the function you want to view or configure.
4. **Device Summary:** All important device information and statistics are shown here.
5. **Maintenance:** Functions for device maintenance are located here.



# Device Summary

After successfully connecting to the AWK Series, the **Device Summary** will automatically appear. To view the device summary from anywhere in the interface, click **Device Summary** on the Function Menu.

The screenshot displays a dashboard with four widgets. The top-left widget, 'Device Information', shows product model (AWK-1161A-UN), country/region (AU), firmware version (v1.1 Build 2024\_0327\_1555), and MAC address (00:90:E8:61:A1:12). The top-right widget, 'System Information', shows device name (moxa-awk-1161a), location (---), description (AWK-1161A), and operation mode (Disabled). The bottom-left widget, 'System Status', shows current time (2024-04-18 21:36:32), system uptime (0d4h28m14s), external storage (---), default gateway (---), netmask (24 (255.255.255.0)), and IPv4 address (192.168.127.253). The bottom-right widget, 'Security Status', shows three risk levels: High Risk (0 / 17), Medium Risk (2 / 7), and Low Risk (5 / 6). A 'VIEW DETAILS' link is located at the bottom right of the Security Status widget.

See the following sections for a detailed description of each widget.

## Device Information

This shows the model information, including product model name, the country or region of RF compliance, and firmware version.

The screenshot shows the 'Device Information' widget with the following details: Product Model (AWK-1161A-UN), Country/Region (AU), Firmware Version (v1.1 Build 2024\_0327\_1555), Bootloader Version (v1.0 Build 2023\_1213\_1647), MAC Address (00:90:E8:61:A1:12), and Serial Number (---).


## System Information

This shows system information including the device name, location, description, and current operation mode.

The screenshot shows the 'System Information' widget with the following details: Device Name (moxa-awk-1161a), Location (---), Description (AWK-1161A), Operation Mode (Disabled), and Device Unique Key Last Updated on (---).

## System Status

This shows the system status, including system time, system uptime, and IP address.




**System Status** 2024-04-18 21:56:03 [↻](#)

Current Time	System Uptime
2024-04-18 21:56:03	0d4h47m45s
External Storage	
---	
Default Gateway	Netmask
---	24 (255.255.255.0)
IPv4 Address	
192.168.127.253	

## Security Status

This section reflects the overall device security status categorized into High, Medium, and Low risks. The accompanying link opens a detailed view of the risk entries to check the risk details at a glance. This allows administrators to evaluate and take mitigation action where necessary.




**Security Status** 2024-04-18 21:58:41 [↻](#)

<b>0 / 17</b> High Risk	<b>2 / 7</b> Medium Risk
<b>5 / 6</b> Low Risk	

[VIEW DETAILS →](#)


## System

The **System** section houses all device and system configuration functions. From here, you can configure the **System Management**, **Account Management**, **Management Interface**, and **Time** settings.



## System Management

The **System Management** section houses three subsections: **System Information**, **Firmware Upgrade**, and **Configure Backup and Restore**.



## System Information

On the **System Information** screen, you can enter a device name, description, and location for the device. This makes it easier to identify different AWKs that are connected to your network.

### System Information

Device Name \*  
moxa-awk-1161a i

14 / 255

Location

0 / 255

Description  
AWK-1161A

9 / 255

Contact Information

0 / 255

APPLY

### Device Name

Setting	Description	Factory Default
1 to 255 characters	Enter a name for the device. This is useful for differentiating between the roles or applications of different units. Note that the device name cannot be empty and must comply with the following naming rules: <ul style="list-style-type: none"><li>• Only supports letters (a-z), numbers (0-9), and special character dash (-)</li><li>• Cannot contain spaces</li><li>• Cannot start with dash (-)</li><li>• Cannot end with dash (-)</li><li>• When used in a PROFINET environment, cannot start with the prefix "port-x" where "x" equals 0 to 9. There is no validity to identify incorrect name formats.</li></ul>	moxa-awk-1161a

### Location

Setting	Description	Factory Default
Max. 255 characters	Enter a location for the device. This is useful for identifying where the device is deployed. Example: production line 1.	None

### Description

Setting	Description	Factory Default
Max. 255 characters	Enter a description for the device.	AWK-1161A

### Contact Information

Setting	Description	Factory Default
Max. 255 characters	Enter the contact information of the person responsible for the device in case there is a problem with the device.	None

When finished, click **APPLY** to save your changes.

## Firmware Upgrade

There are four ways to update your AWK's device firmware: from a local \*.rom file, by remote TFTP server, remote SFTP server, or the ABC-02 tool.

### Local

Select **Local** from the Source drop-down list. Before performing the firmware upgrade, download the target firmware (\*.rom) file first from Moxa's website ([www.moxa.com](http://www.moxa.com)) to the local host.


## Firmware Upgrade

Running Firmware Version  
v1.1 Build 2024\_0327\_1555

---

Uploaded Firmware Version  
---

Source \*  
Local

Select File \* 

### Running Firmware Version

Setting	Description	Factory Default
Current firmware version number	This shows the current running firmware version.	Current running version

### Uploaded Firmware Version

Setting	Description	Factory Default
New firmware version number	This shows the new firmware version.	None

### Select File

Setting	Description	Factory Default
Select the firmware file	Click the browse icon and navigate to the firmware file on the local host.	None

When finished, click **UPLOAD** to upload the file, then click **UPGRADE** to perform the firmware upgrade.

### TFTP Server

Select **TFTP** from the Source drop-down list.

## Firmware Upgrade

TFTP does not support user authentication and sends all data in cleartext. We recommend using another method.

Running Firmware Version  
v1.1 Build 2024\_0327\_1555  
.....

Uploaded Firmware Version  
---  
.....

Source \*  
TFTP ▾

Server IP Address \*      Filename \*  
0 / 256

### Running Firmware Version

Setting	Description	Factory Default
Current firmware version number	This shows the current running firmware version.	Current running version

### Uploaded Firmware Version

Setting	Description	Factory Default
New firmware version number	This shows the new firmware version.	None

### Server IP Address

Setting	Description	Factory Default
TFTP server address	Enter the IP address of the TFTP server where the new firmware file (*.rom) is located.	None

### File Name

Setting	Description	Factory Default
Firmware file name	Enter the file name of the new firmware.	None

When finished, click **UPLOAD** to upload the file, then click **UPGRADE** to perform the firmware upgrade.

## SFTP

Select **SFTP** from the Source drop-down list.

### Firmware Upgrade

Running Firmware Version  
v1.1 Build 2024\_0327\_1555


---

Uploaded Firmware Version  
---

---

Source \*  
SFTP

Server IP Address \*      Filename \*  
0 / 256

Account \*      Password \* 

### Running Firmware Version

Setting	Description	Factory Default
Current firmware version number	This shows the current running firmware version.	Current running version

### Uploaded Firmware Version

Setting	Description	Factory Default
New firmware version number	This shows the new firmware version.	None

### Server IP Address

Setting	Description	Factory Default
SFTP server address	Enter the IP address of the SFTP server where the new firmware file (*.rom) is located.	None

### File Name

Setting	Description	Factory Default
Firmware file name	Enter the file name of the new firmware.	None

### Account

Setting	Description	Factory Default
SFTP server account	Enter the SFTP user account name. This account must be authorized to ensure a secure connection to the SFTP server.	None

### Password

Setting	Description	Factory Default
SFTP server password	Enter the SFTP user account password. This account must be authorized to ensure a secure connection to the SFTP server.	None

When finished, click **UPLOAD** to upload the file, then click **UPGRADE** to perform the firmware upgrade.

## ABC-02

Select **ABC-02** from the Source drop-down. This method requires the Moxa ABC-02 USB configuration backup and restoration tool with the target firmware file is connected to the device. You can download the


target firmware (\*.rom) file from Moxa's website ([www.moxa.com](http://www.moxa.com)). For more information about the Moxa ABC-02 Series USB tool, visit the [product page](#).

## Firmware Upgrade

Running Firmware Version  
v1.0 Build 2021\_0810\_0019  
.....

Uploaded Firmware Version  
---  
.....

Source \*  
ABC-02 ▾

Select File \* 

UPLOAD
UPGRADE

### ***Running Firmware Version***

Setting	Description	Factory Default
Current firmware version number	This shows the current running firmware version.	Current running version

### ***Uploaded Firmware Version***

Setting	Description	Factory Default
New firmware version number	This shows the new firmware version.	None

### ***Select File***

Setting	Description	Factory Default
Select the firmware file	Click the browse icon and navigate to the firmware file on the attached ABC-02 device.	None

When finished, click **UPLOAD** to upload the file, then click **UPGRADE** to perform the firmware upgrade.

## Configuration Backup and Restore

There are four ways to back up and restore your Moxa AWK's configuration: from a local configuration file, by remote TFTP server, remote SFTP server, or an ABC-02 USB backup and restoration tool.

For all Backup and Restore methods, users can enable or disable CA signature. Enabling this function provides additional security by verifying the integrity of the configuration file.

### Backup


The **Backup** tab is used to export a backup of the current configuration. This backup file can then be used to restore the device's configuration settings, or to import it to other AWK Series devices.

### Configuration Backup and Restore

Backup    Restore

Configuration Source \*  
Running Configuration

Storage Location \*  
Local

Configuration Password \*   
0 / 64

BACK UP

### Local


Select **Local** first from the Storage Location drop-down list.

### Configuration Backup and Restore

Backup    Restore

Configuration Source \*  
Running Configuration

Storage Location \*  
Local

Configuration Password \*   
0 / 64

BACK UP

#### Configuration Source

Setting	Description	Factory Default
Running Configuration	Back up the running configuration.	



Setting	Description	Factory Default
Startup Configuration	Back up the start-up configuration.	Running Configuration

### Storage Location

Setting	Description	Factory Default
<b>Local</b>	<b>Back up the configuration files for the local computer.</b>	Local
TFTP	Back up the configuration files via TFTP.	
SFTP	Back up the configuration files via SFTP.	
ABC-02	Back up the configuration files via ABC-02 USB tool.	

### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file. For firmware v2.0 and above, the password must be at least 8 characters long.	None

When finished, click **BACK UP**.

### TFTP Server

Select **TFTP** first from the Storage Location drop-down list.

## Configuration Backup and Restore

Backup
Restore

TFTP does not support user authentication and sends all data in clear text. We recommend using SFTP to back up the configuration files.

Configuration Source \*

Running Configuration ▼

Storage Location \*

TFTP ▼

Server IP Address \*

0 / 253

Filename \*

0 / 256

Configuration Password \*

0 / 64

### Configuration Source

Setting	Description	Factory Default
Running Configuration	Back up the running configuration.	Running
Startup Configuration	Back up the start-up configuration.	Configuration

### Storage Location

Setting	Description	Factory Default
Local	Back up the configuration files for the local computer.	Local
<b>TFTP</b>	<b>Back up the configuration files via TFTP.</b>	
SFTP	Back up the configuration files via SFTP.	
ABC-02	Back up the configuration files via ABC-02 USB tool	

### Server IP Address

Setting	Description	Factory Default
TFTP server address	Enter the IP address of the TFTP server.	None

### File Name

Setting	Description	Factory Default
Max. 256 characters (including the .ini file extension).	Enter the configuration backup file name.	None

### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **BACK UP**.

### SFTP Server

Select **SFTP** first from the Storage Location drop-down list.

## Configuration Backup and Restore

Backup Restore

Configuration Source \*

Running Configuration

Storage Location

SFTP

Server IP Address \* 0 / 253      Filename \* 0 / 256

Account \* 0 / 256      Password \* 0 / 256

Configuration Password \* 0 / 64

**BACK UP**

### Configuration Source

Setting	Description	Factory Default
Running Configuration	Back up the running configuration.	Running
Startup Configuration	Back up the start-up configuration.	Configuration

### Storage Location

Setting	Description	Factory Default
Local	Back up the configuration files for the local computer.	Local
TFTP	Back up the configuration files via TFTP.	
<b>SFTP</b>	<b>Back up the configuration files via SFTP.</b>	
ABC-02	Back up the configuration files via ABC-02 USB tool	

### Server IP Address

Setting	Description	Factory Default
SFTP server address	Enter the IP address of the SFTP server where the new firmware file (*.rom) is located.	None

### File Name

Setting	Description	Factory Default
Max. 256 characters (including the .ini file extension).	Enter the configuration backup file name.	None

### Account

Setting	Description	Factory Default
SFTP server account	Enter the SFTP user account name. This account must be authorized to ensure a secure connection to the SFTP server.	None

### Password

Setting	Description	Factory Default
SFTP server password	Enter the SFTP user account password. This account must be authorized to ensure a secure connection to the SFTP server.	None

### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **BACK UP**.

### ABC-02

Select **ABC-02** from the Storage Location drop-down list. This method requires a Moxa ABC-02 configuration backup and restore USB tool to be connected to the AWK Series.

## Configuration Backup and Restore

Backup Restore

Configuration Source \*  
Running Configuration

Storage Location \*  
ABC-02

Backup for System Initialization \*  
No

Select Folder \*

Configuration Password \*  
0 / 64

**BACK UP**

### Configuration Source

Setting	Description	Factory Default
Running Configuration	Back up the running configuration.	Running
Startup Configuration	Back up the start-up configuration.	Configuration

### Storage Location

Setting	Description	Factory Default
Local	Back up the configuration files for the local computer.	Local
TFTP	Back up the configuration files via TFTP.	
SFTP	Back up the configuration files via SFTP.	
<b>ABC-02</b>	<b>Back up the configuration files via ABC-02 USB tool.</b>	

### Backup for System Initialization

Setting	Description	Factory Default
Yes	Back up the system initialization files.	No
No	Do not back up the system initialization files.	

### Select Folder

Setting	Description	Factory Default
Folder path	Navigate to the folder path of the ABC-02 tool.	None

### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **BACK UP**.

## Automatic Backup to ABC-02

The AWK-Series also supports automatic configuration backups when using a Moxa ABC-02 backup and restore tool.

#### Automatically Back Up Configurations to ABC-02

Auto Backup Status \*

Disabled

### Auto Backup Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable automatically backing up the device's configuration to the ABC-02.	Disabled

When finished, click **APPLY**.

## Restore

From the **Restore** tab you restore the device's configuration using a previously created backup file.

## Configuration Backup and Restore


Backup
Restore

Source \*

Local ▼


---

Select File \*



---

Configuration Password \*



0 / 64

RESTORE

### Local

#### Source

Setting	Description	Factory Default
<b>Local</b>	<b>Restore the configuration from a local backup file.</b>	Local
TFTP	Restore the configuration from a backup file via TFTP.	
SFTP	Restore the configuration from a backup file via SFTP.	
ABC-02	Restore the configuration from a backup file on an ABC-02 USB tool.	

#### Select File

Setting	Description	Factory Default
Backup file	Click the browse icon and navigate to the backup file on the local host.	None

#### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **RESTORE**.

## TFTP Server

### Configuration Backup and Restore

Backup **Restore**

TFTP does not support user authentication and sends all data in clear text. We recommend using SFTP to restore the configuration files.

Source  
TFTP

Server IP Address \*  0 / 253      Filename \*  0 / 256

Configuration Password \*  0 / 64

**RESTORE**

#### Source

Setting	Description	Factory Default
Local	Restore the configuration from a local backup file.	Local
<b>TFTP</b>	<b>Restore the configuration from a backup file via TFTP.</b>	
SFTP	Restore the configuration from a backup file via SFTP.	
ABC-02	Restore the configuration from a backup file on an ABC-02 USB tool.	

#### Server IP Address

Setting	Description	Factory Default
TFTP server address	Enter the IP address of the TFTP server.	None

#### File Name

Setting	Description	Factory Default
Max. 256 characters (including the .ini file extension)	Enter the file name of the configuration backup file.	None

#### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **RESTORE**.

## SFTP Server

### Configuration Backup and Restore

Backup
Restore

Source \*  
SFTP ▼

Server IP Address \* Filename \*  
   
0 / 253 0 / 256

Account \* Password \*   
   
0 / 256 0 / 256

Configuration Password \*   
  
0 / 64

RESTORE

#### Source

Setting	Description	Factory Default
Local	Restore the configuration from a local backup file.	Local
TFTP	Restore the configuration from a backup file via TFTP.	
<b>SFTP</b>	<b>Restore the configuration from a backup file via SFTP.</b>	
ABC-02	Restore the configuration from a backup file on an ABC-02 USB tool.	

#### Server IP Address

Setting	Description	Factory Default
SFTP server address	Enter the IP address of the SFTP server where the new firmware file (*.rom) is located.	None

#### File Name

Setting	Description	Factory Default
Max. 256 characters (including the .ini file extension).	Enter the filename of the configuration restoration file.	None

#### Account

Setting	Description	Factory Default
SFTP server account	Enter the SFTP user account name. This account must be authorized to ensure a secure connection to the SFTP server.	None

#### Password

Setting	Description	Factory Default
SFTP server password	Enter the SFTP user account password. This account must be authorized to ensure a secure connection to the SFTP server.	None

#### Configuration Password

Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **RESTORE**.

## ABC-02

### Configuration Backup and Restore

Backup Restore

Source  
ABC-02

Select File \*

Configuration Password \*  
0 / 64

RESTORE

#### Source

Setting	Description	Factory Default
Local	Restore the configuration from a local backup file.	Local
TFTP	Restore the configuration from a backup file via TFTP.	
SFTP	Restore the configuration from a backup file via SFTP.	
<b>ABC-02</b>	<b>Restore the configuration from a backup file on an ABC-02 USB tool.</b>	

#### Select File

Setting	Description	Factory Default
Backup file	Click the browse icon and navigate to the backup file on the local host.	None

#### Configuration Password


Setting	Description	Factory Default
Configuration password	Enter the configuration password. You will need to enter this password when importing the backup file.	None

When finished, click **RESTORE**.



## Automatic Restore From ABC-02

The AWK Series supports automatic configuration restoration when using a Moxa ABC-02 backup and restore tool.



**Automatically Restore Configurations from ABC-02**

Auto Restore Status \*

Disabled

APPLY

### Auto Restore Status


Setting	Description	Factory Default
Enabled/Disabled	Enable or disable automatically restoring the device's configuration from an ABC-02.	Disabled

When finished, click **APPLY** to change your setting.

## Fast Boot-up

The AWK Series is designed with comprehensive security mechanisms to verify device integrity during boot-up. These security measures take time to process before the system is fully operational to provide wireless connectivity services. For applications that require fast connectivity services after a cold start, the Fast Boot-up feature skips some of the startup processes, including the configuration file verification and regeneration, to speed up the overall boot up time by around 30 seconds.

Please note that skipping the configuration file regeneration process to shorten the boot time implies that the device will be running the configuration file saved on the eMMC without prior verification. This could potentially be a security concern if the device has been physically accessed and the eMMC storage was tampered with.



**Fast Boot-up**

Status \*

Disabled

If enabled, the configuration will not be regenerated when the device boots up and may pose a potential security concern.

APPLY


### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable fast boot-up.	Disabled

When finished, click **APPLY**.

## Account Management

From this section, you can manage User Account settings and the Password Policy.



Account Management ^

User Account


Password Policy

## User Account

The **User Account** section lets you manage user accounts authorized to access this device and configure account privileges. You can choose to store user accounts on a RADIUS server or manage user accounts locally on the device. Click **User Account** under **Account Management** to access this configuration screen.

### Create a New Local Account

To create a new user account, click the **Settings** tab, then click the Add  icon.



<input type="checkbox"/>	Status	Username	Email
<input type="checkbox"/>	Enabled	admin	moax@moxa.com



Max 32

Edit the following settings:

### Create New Account

Status \*  
 Disabled ▼

Username \*  
 At least 4 characters 0 / 32

New Password \*  Confirm Password \*   
 At least 4 characters 0 / 63 At least 4 characters 0 / 63

Email  
 0 / 318

Role \*  
 User ▼

Authority \*

- Account System
- Advanced Diagnostics
- Auditor System
- Diagnostics
- Network Configuration
- Status Monitoring
- System Backup
- System Management

CANCEL APPLY

**Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the user account.	Disabled

**Username**

Setting	Description	Factory Default
Min. 4 characters	Enter a username for this account.	None

### New Password

Setting	Description	Factory Default
Min. 8 characters	Enter the password for this account. For better protection, it is recommended to enforce stronger password complexity by enabling the following <a href="#">Password Policy</a> requirements: At least one digit (0-9) At least one upper case letter (A-Z) At least one lower case letter (a-z) At least one special character (~!@#\$%^&*-_!;,:.<>{}[]())	None

### Confirm Password

Setting	Description	Factory Default
Password	Enter the account password again for confirmation.	None

### Email

Setting	Description	Factory Default
Email	Enter the email address for this account.	None

### Role

Setting	Description	Factory Default
Administrator	Set the user's role to Administrator. This role provides full access to all configurations on the device. (pre-defined authority)	User
Engineer	Set the user's role to Engineer. (pre-defined authority)	
User	Set the user's role to User. (pre-defined authority)	
Custom	If a mix of authorities is necessary, create an account via the Custom option and manually select the necessary authorities for this account.	

### Authority

Setting	Description	Factory Default
Checkbox	Checking authorities gives the user the ability to access configurations pages in the corresponding category. These authority privileges extend to all access interfaces, including CLI.	None

Refer to the table below for an overview of each role and corresponding authorities.

Authority	Admin	Engineer	User
Account System	Yes	No	No
Advanced Diagnostic	Yes	Yes	No
Auditor System	Yes	Yes	No
Diagnostic	Yes	Yes	Yes
Network	Yes	Yes	No
Status Monitoring	Yes	Yes	Yes
System Backup	Yes	No	No
System Management	Yes	Yes	No




## NOTE

The Administrator, Engineer, and User roles have pre-defined authority options and cannot be changed. The Administrator has all authorities enabled by default. The Custom role allows you to select specific authorities for the user account.

Refer to Appendix D for a detailed overview of the required authority for each device feature or service to determine the privilege requirements when setting up an account.

When finished, click **APPLY** to create a new account.

## Edit an Existing Local Account

Click the Edit icon  of the account you want to edit.

<input type="checkbox"/>	Status	Username	Email	Role	Account System	Advanced Diagnostics	Auditor System	Diagnostics	Network Configuration	Status Monitoring	System Backup	System Management
<input type="checkbox"/>	Enabled	admin	moxa@moxa.com	Administrator	✓	✓	✓	✓	✓	✓	✓	✓
<input type="checkbox"/>	Enabled	test	test@example.com	User				✓		✓		



Items per page: 20 1 - 2 of 2 < > >>

Edit the account settings. Refer to [Create a New Account](#) for a description of each setting.

### Edit Account

Status \*  
Enabled

Username  
test

New Password  0 / 63      Confirm Password  0 / 63

Email  
test@example.com 16 / 318

Role \*  
User


**Authority \***


- Account System
- Advanced Diagnostics
- Auditor System
- Diagnostics
- Network Configuration
- Status Monitoring
- System Backup
- System Management




[CANCEL](#) [APPLY](#)

When finished, click **APPLY**.

## Delete an Existing Local User

To delete one or more existing users, check the user(s) you want to delete and click the **Delete**  icon on the top of the page.



	Status	Username	Email	Role
<input type="checkbox"/>	 Enabled	admin	moxa@moxa.com	Administrator
<input checked="" type="checkbox"/>	 Enabled	test	test@example.com	User

### Delete Account

Are you sure you want to delete the selected account?

CANCEL


DELETE

Click **DELETE** to delete the user.

## Terminate the Active Session of a User



If necessary, you can manually terminate a specific user's active session for a specific interface. This will also record an event log.

Click **Session Management** tab and click the **Terminate Session**  icon next to the user.



### User Account

Settings   **Session Management**   RADIUS

Username	WEB: Status	WEB: Last Login	WEB: Last Activity
 Engineer	In Use	2024-04-18 22:32:24+00:00	2024-04-18 22:32:26+00:00
 admin	In Use	2024-04-18 21:50:42+00:00	2024-04-18 22:32:31+00:00

Max 32

When prompted, select which active sessions you want to terminate.

### Terminate Session

Which active session(s) do you want to terminate?

WEB

CLI

MXconfig

CANCEL
TERMINATE

Click **TERMINATE** to end the selected sessions. The user will be logged out of the corresponding interfaces immediately.

## Edit the Password Policy

To edit the password policy, click **Password Policy** under **Account Management** in the function menu tree.

### Password Policy

Minimum Length \*

8

8 - 63

Password Validation Rules

Must include at least one digit (0-9)

Must include at least one uppercase letter (A-Z)

Must include at least one lowercase letter (a-z)

Must include at least one special character (~!@#\$%^&\*-\_!;,:.<>{}[]())

Password Lifetime \*

90

0 - 365 day(s)

APPLY

### Minimum Length

Setting	Description	Factory Default
8 to 63	Specify the required user account password length based on your organization's password length policy. To comply with IEC 62443 requirements, the minimum length starts at 8.	8

### Password Validation Rules

Setting	Description	Factory Default
Selectable checkboxes	Select check box to enforce the required password complexity: At least one digit (0-9) At least one upper case letter (A-Z) At least one lower case letter (a-z) At least one special character (~!@#\$%^&*-_!;,:.<>{}[]())	Unchecked




### Password Lifetime

Setting	Description	Factory Default
0 to 365 day(s)	Specify the maximum password lifetime. At the end of this duration, the password will expire, and users will be requested to create a new password.	90

When finished, click **APPLY**.

## Management Interface

The **Management Interface** section houses the **User Interface**, **Hardware Interface**, and **SNMP configuration** screens.



### User Interface

The **User Interface** configuration screen lets you manage the interfaces available to users to access the device. Click **User Interface** under **Management Interface** to access this screen.

## User Interface

HTTP and Telnet are not secure interface. We recommend disabling these.

HTTP Status *	HTTP: TCP Port *
Enabled ▼	80
	1 - 65535
HTTPS Status *	HTTPS - TCP Port *
Disabled ▼	443
	1 - 65535
Telnet Status *	Telnet - TCP Port *
Disabled ▼	23
	1 - 65535
SSH Status *	SSH - TCP Port *
Enabled ▼	22
	1 - 65535
SNMP Status *	SNMP - UDP Port *
Disabled ▼	161
	1 - 65535
Moxa Service Status *	Moxa Service - UDP Port
Enabled ▼	40404
	.....
Max. number of Login Session For HTTP + HTTPS *	
5	
1 - 10	
Max. number of Login Session for Telnet + SSH + Serial Console *	
5	
1 - 10	
<input type="button" value="APPLY"/>	

### HTTP Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable HTTP connections.	Disabled



## NOTE

If HTTP and HTTPS are both enabled, any HTTP session will automatically redirect to HTTPS.

### HTTP – TCP Port

Setting	Description	Factory Default
1 to 65535	Specify the HTTP interface TCP port number.	80

### HTTPS Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable HTTPS connections.	Enabled

### HTTPS – TCP Port

Setting	Description	Factory Default
1 to 65535	Specify the HTTPS interface TCP port number.	443

### Telnet Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Telnet connections.	Disabled

**Telnet – TCP Port**

Setting	Description	Factory Default
1 to 65535	Specify the Telnet interface TCP port number.	23

**SSH Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable SSH connections.	Enabled

**SSH – TCP Port**

Setting	Description	Factory Default
1 to 65535	Specify the SSH interface TCP port number.	22

**SNMP Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable SNMP.	Disabled

**SNMP – Port**

Setting	Description	Factory Default
1 to 65535	Specify the SNMP UDP port number.	161

**Moxa Service Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Moxa Service.	Enabled

**NOTE**

Moxa Service is only for Moxa network management software such as MXconfig.

**Moxa Service (Encrypted)**

Setting	Description	Factory Default
40404 (read only)	Specify the Moxa Service UDP port.	40404

**Maximum number of Login Sessions for HTTP + HTTPS**

Setting	Description	Factory Default
1 to 10	Specify the maximum number of concurrent HTTP+HTTPS login sessions allowed on the device.	5

**Maximum number of Login Sessions for Telnet + SSH + Serial Console**

Setting	Description	Factory Default
1 to 10	Specify the maximum number of concurrent Telnet, SSH, and Serial login sessions allowed on the device.	5

When finished, click **APPLY**.

## Hardware Interface

From the **Hardware Interface** screen, you can manage the physical interfaces on the device. Click **Hardware Interface** under **Management Interface** to access this screen.

### Hardware Interface

Reset Button Status \*

Reset Button Active Duration \*  
  
0 - 300 sec.

Serial Status \*

USB Status \*

Configure the following settings:

### **Reset Button Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the reset button.	Disabled

### **Reset Button Active Duration**

Setting	Description	Factory Default
0 to 300 (sec.)	<p>If the reset button is disabled, the "Active Duration" defines the grace period (in seconds) where the reset button will be active for after a system cold boot up. After the grace period, the reset button will be disabled.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• If set to 0, the reset button will always be disabled.</li> <li>• The Active Duration countdown begins as soon as the WLAN LED indicator turns from amber to off after the boot up process.</li> </ul>	220

### **Serial Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the serial console port.	Enabled

### **USB Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the USB port.	Disabled

When finished, click **APPLY**.

## SNMP

The Moxa AWK Series supports SNMP V1, V2c, and V3. SNMP V1 and SNMP V2c use a community string match for authentication, which means that SNMP servers access all objects with read-only or read/write permissions using the default “public” and “private” community strings. SNMP V3 requires MD5 or SHA authentication. You can also enable data encryption to enhance data security.

The supported SNMP security modes and levels are shown in the table below. Select the security mode and level that will be used to communicate between the SNMP agent and manager.

Protocol Version	UI Setting	Authentication	Encryption	Method
SNMP V1, V2c	V1, V2c Read Community	Community string	None	Uses a community string match for authentication.
	V1, V2c Write/Read Community	Community string	None	Uses a community string match for authentication.
SNMP V3	None	None	None	Uses an account with admin or user role to access objects.
	MD5 or SHA	Authentication based on MD5 or SHA	Disabled	Uses authentication based on HMAC-MD5, or HMAC-SHA algorithms. 8-character passwords are the minimum requirement for authentication.
	MD5 or SHA	Authentication based on MD5 or SHA	Data encryption key: DES, AES	Uses authentication based on HMAC-MD5 or HMAC-SHA algorithms, and a data encryption key. 8-character passwords and a data encryption key are the minimum requirements for authentication and encryption.

## Configure SNMP Settings

From the **SNMP** screen you can configure the SNMP status and manage the SNMP account. Click **SNMP** from the function tree to access this screen.

### SNMP

SNMP
SNMP Account List

SNMP V1 and V2c are not secure. We recommend using SNMP V3.

SNMP Status \*  
Disabled

APPLY

### SNMP Status

Setting	Description	Factory Default
Read/Write	Set SNMP to read-write.	Disabled
Read Only	Set SNMP as read-only.	
Disabled	Disable the SNMP.	

### SNMP Version

Setting	Description	Factory Default
V1, V2c, V3	Enable SNMP V1, V2c, and V3.	V3 only
V1, V2c	Enable SNMP V1 and V2c.	
V3 only	Enable SNMP V3 only.	

### Read Community (for V1/V2c Versions)

Setting	Description	Factory Default
Public/Private	Specify the read community security authority level.	public

### Read/Write Community (for V1/V2c Versions)

Setting	Description	Factory Default
Public/Private	Specify the read/write community security authority level.	private



#### NOTE

SNMP V1 and V2c are not secure. We highly recommend using SNMP V3.



#### NOTE

While the AWK-1161A, AWK-1165A, AWK-1161C, and AWK-1165C Series use the same firmware and MIB structure, since the -C Series and -A Series only support client and AP feature sets respectively, please be aware that SNMP read or write to non-applicable OIDs will return "0 disabled" and "not support" messages.


When finished, click **APPLY**.

## Edit an SNMP Account

On the SNMP Account List tab, click the Edit icon  of the account you want to edit.

### SNMP

SNMP    SNMP Account List

Username	Status	SNMP Status	Authority	Authentication Type	Encryption Method
 admin	Enabled	Disabled	Read Write	None	None

Configure the following settings:

### Edit SNMP Account Settings

Username  
admin

SNMP Status \*  
Enabled

Authority  
Read/Write

Authentication Type  
None

CANCEL APPLY

#### **Username**

Setting	Description	Factory Default
admin (read only)	Show the username. This cannot be changed.	Username for the current user

#### **SNMP Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable SNMP.	Disabled

#### **Authority**

Setting	Description	Factory Default
Read/Write	Give the SNMP account as Read/Write authority.	Read/Write
Read Only	Give the SNMP account Read Only authority.	

#### **Authentication Type**

Setting	Description	Factory Default
None	No authority type selected.	None
MD5	Specify MD5 as the authority type.	
SHA	Specify SHA as the authority type.	

#### **Authentication Password**

Setting	Description	Factory Default
8 to 63 characters	Depending on the selected Authentication Type, specify the Authentication Password. The password must be at least 8 characters long.	None

#### **Encryption Method**

Setting	Description	Factory Default
None	No encryption method selected.	None
DES	Specify DES as the Encryption Method.	
AES	Specify AES as the Encryption Method.	


#### **Encryption Key**

Setting	Description	Factory Default
8 to 63 characters	Depending on the selected Encryption Method, specify the Encryption Key. The password must be at least 8 characters long.	None

When finished, click **APPLY**.

# Time

From the **Time** section, you can configure the **System Time**.




## System Time

The **System Time** screen lets you configure the device time settings and specify the time zone. Click **System Time** under **Time** in the function tree to access this screen.

### Edit the Clock

The system clock, time, and date can be set manually, or be synced to an external time server.



Configure the following settings:



### ATTENTION

You must select the time zone first before configuring "System Clock" settings, as any changes made to the time zone after the system clock has been configured will shift the clock offset based on the deviation of the selected time zone.

#### Current Time

Setting	Description	Factory Default
Current Time (read only)	Shows the current time.	Current Time

#### Clock Source

Setting	Description	Factory Default
Internal Clock	Set the clock source to internal. This requires the date and time to be specified manually.	Internal Clock
NTP	Set the clock source to NTP. This will sync the system clock with an external NTP server.	



## Configure the Time and Date (Internal Clock)

### Date

Setting	Description	Factory Default
Day of the month	Select the current date.	Local

### Time

Setting	Description	Factory Default
hh, mm, ss	Specify the current time using the 12-hour AM/PM format. You can manually input the time, or you can click <b>Sync From Browser</b> to sync the time with your web browser.	Sync From Browser

## Configure Time Servers (NTP)

### Time Server 1

Setting	Description	Factory Default
NTP time server	Specify the IP or domain address of the primary NTP server to use (e.g., 192.168.1.1, time.stdtime.gov.tw, or time.nist.gov).	None

### Time Server 2

Setting	Description	Factory Default
NTP time server	Specify the IP or domain address of the secondary NTP server. The secondary NTP server acts as a backup in case the device fails to connect to the first NTP server.	None

### Sync Interval

Setting	Description	Factory Default
10 to 1440 (sec.)	Specify the interval (in seconds) at which the system will sync the clock with the time server.	10

When finished, click **APPLY**.

## Edit the Time Zone

You can specify the system clock time zone and apply daylight saving time.

Click the **Time Zone** tab.

**System Time**

System Clock | Time Zone

Time Zone \*  
UTC+00:00

Daylight Saving  
Daylight Saving Status \*  
Disabled

APPLY

Configure the following settings:

### Time Zone

Setting	Description	Factory Default
Time zone	Select a time zone.	GMT (Greenwich Mean Time)

### Daylight Saving Time

The Daylight Saving Time settings are used to automatically adjust the time according to regional standards.

### Daylight Saving

Daylight Saving Status <sup>\*</sup>

Enabled ▼

---

Offset <sup>\*</sup>

00:00

---

**Start**

Month <sup>\*</sup> Week <sup>\*</sup> Day <sup>\*</sup> Hour <sup>\*</sup>

Jan ▼ 1st ▼ Sun ▼ 00 ▼

---

**End**

Month <sup>\*</sup> Week <sup>\*</sup> Day <sup>\*</sup> Hour <sup>\*</sup>

Jan ▼ 1st ▼ Sun ▼ 00 ▼

---

**APPLY**

**Daylight Saving Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Daylight Saving Time.	Disabled

**Offset**

Setting	Description	Factory Default
User-specified value	Specify the offset value for Daylight Saving Time.	None

**Start**

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time begins.	Jan, 1st, Sun, 00.

**End**

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time ends.	Jan, 1st, Sun, 00

When finished, click **APPLY**.

# Wi-Fi


From the Wi-Fi section, you can configure the Wireless Settings, Connection Check and Recovery, and Roaming.




## NOTE

The feature menu appears slightly different between AWK-1160A Series models and AWK-1160C Series models.

AWK-1161A/AWK-1165A Series



AWK-1161C/AWK-1165C Series




## Wireless Settings

On the **Wireless Settings** page, you can configure the device's operating mode, SSID, MAC Cloning settings, as well as check the Wi-Fi connection status. Click **Wireless Settings** under **Wi-Fi** in the function tree to access this screen.

## General Settings

The **General** section is used for setting the AWK's operation mode, creating SSIDs, and configuring RF settings. Click the **General** tab to access this screen.



Configure the following settings:

**Operation Mode**



**NOTE**

The available operation modes depend on the model.

- A Series models: AP, Master, Sniffer modes only
- C Series models: Client, Client-Router, Slave, Sniffer modes only.

Setting	Description	Factory Default
Disabled	Disable the operation mode.	Disabled
AP	Specify the operation mode as AP. Refer to <b>AP Mode Settings</b> . (AWK-1161A, AWK-1165A only)	
Master	Specify the operation mode as Master. Refer to <b>Master Mode Settings</b> . (AWK-1161A, AWK-1165A only)	
Sniffer	Specify the operation mode as Sniffer. Refer to <b>Sniffer Mode Settings</b> .	
Client	Specify the operation mode as Client. Refer to <b>Client Mode Settings</b> . (AWK-1161C, AWK-1165C only)	
Client-Router	Specify the operation mode as Client-Router. Refer to <b>Client-Router Mode Settings</b> . (AWK-1161C, AWK-1165C only)	
Slave	Specify the operation mode as Slave. Refer to <b>Slave Mode Settings</b> . (AWK-1161C, AWK-1165C only)	


**AP Mode Settings**

Select **AP** from the drop-down list of **Operation Mode**. AP Mode requires at least one active SSID.



**NOTE**

AP mode is only supported by the AWK-1161A and AWK-1165A Series.



### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

For SSID and security settings, refer to **Create a New SSID**.

For configuring RF settings, refer to **RF Settings**.

When finished, click **APPLY** to change the operation mode.


## Master Mode Settings

Select **Master** from the drop-down list of **Operation Mode**. Master Mode requires at least one active SSID.



### NOTE

Master mode is only supported by the AWK-1161A and AWK-1165A Series.



### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

For SSID and security settings, refer to **Create a New SSID**.

For configuring RF settings, refer to **RF Settings**.

When finished, click **APPLY** to change the operation mode.

## Sniffer Mode Settings

Select **Sniffer** from the drop-down list of **Operation Mode**.

## Wireless Settings

General
MAC Cloning
Status

The service [Sniffer] is not secure interface. We recommend disabling it.

Operation Mode \*  
Sniffer

Environment \*  
Indoor

RF Band \*  
5 GHz

Security \*  
None

**RF Settings ^**

5 GHz  
Channel Width \*  
20/40/80 MHz

Channel \*  
36 (5180 MHz)

Bonded Channel(s)  
40, 44, 48

Antenna \*  
All

Antenna Gain  
2  
0 - 18 dBi

**APPLY**

Configure the following settings:

### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

### RF Band

Setting	Description	Factory Default
5 GHz	Select 5 GHz as the RF band.	5 GHz
2.4 GHz	Select 2.4 GHz as the RF band.	
5 GHz & 2.4 GHz	Select both 5 GHz and 2.4 GHz as the RF bands.	

For configuring RF settings, refer to **RF Settings**.

When finished, click **APPLY** to change the operation mode.



## NOTE

Once Sniffer and RF settings have been configured, you can add the device's IP as an interface in your network capturing software (e.g. Wireshark) and start capturing packets using Sniffer mode.

## Client Mode Settings

Select **Client** from the drop-down list of **Operation Mode**. Client Mode requires at least one active SSID.



## NOTE

Client mode is only supported by the AWK-1161C and AWK-1165C Series.

## Wireless Settings

General	MAC Cloning	Status
Operation Mode * Client	Environment * Indoor	

Configure the following settings:

### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

For SSID and security settings, refer to **Create a New SSID**.

For configuring RF settings, refer to **RF Settings**.

For configuring advanced settings, refer to **Advanced RF Settings**.

When finished, click **APPLY** to change the operation mode.

## Client-Router Mode Settings

Client-Router mode allows you to enable Network Address Translation (NAT) functionality to forward data to LAN ports of connected devices.

Select **Client-Router** from the drop-down list of **Operation Mode**. Client-Router Mode requires at least one active SSID.



### NOTE

Client-Router mode is only supported by the AWK-1161C and AWK-1165C Series.

General	MAC Cloning	Status
Operation Mode * Client-Router	Environment * Indoor	

Configure the following settings:

### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

For SSID and security settings, refer to **Create a New SSID**.

For configuring RF settings, refer to **RF Settings**.

For configuring advanced settings, refer to **Advanced RF Settings**.

When finished, click **APPLY** to change the operation mode.



## Slave Mode Settings

Select **Slave** from the drop-down list of **Operation Mode**. Slave Mode requires at least one active SSID.



### NOTE

Client mode is only supported by the AWK-1161C and AWK-1165C Series.

### Wireless Settings

General	MAC Cloning	Status
Operation Mode * Slave	Environment * Indoor	

Configure the following settings:

#### Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

For SSID and security settings, refer to **Create a New SSID**.

For configuring RF settings, refer to **RF Settings**.

For configuring advanced settings, refer to **Advanced RF Settings**.

When finished, click **APPLY** to change the operation mode.

## Add a New SSID (AP, Master Mode only)

For AP and Master operation modes, configure and enable the SSID profile. There are no SSIDs on the device by default. To add a new SSID, click the **Add** icon.



### NOTE

For more information about Client, Client-Router, and Slave Mode SSID settings, refer to the [Wi-Fi Basic](#) section.

SSID Settings ^

Add
Search

	SSID	RF Band	Security	Encryption	Status
<input type="checkbox"/>	Moxa-5G	5 GHz	WPA2 (Personal)	AES	Enabled
<input type="checkbox"/>	Moxa-2G	2.4 GHz	WPA2 (Personal)	AES	Enabled

Max 9

Configure the following settings:

**Configure SSID Settings**

SSID \*  
Moxa-5G  
At least 1 character 7 / 32

RF Band \*  
5 GHz

RTS / CTS Threshold \*  
2346  
32 - 2346 bytes

**Transmission Rate: 5 GHz**

Data Transmission Rate \*  
Auto

Min. Data Transmission Rate \*  
0  
0 - 65 Mbps

Broadcast/Multicast Data Transmission Rate \*  
HT-MCS5

Management Transmission Rate \*  
HT-MCS5

CANCEL NEXT

### SSID Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the SSID.	Disabled

### SSID

Setting	Description	Factory Default
1 to 32 characters	Enter a name for the SSID.	None

### RF Band

Setting	Description	Factory Default
2.4 GHz	Use the 2.4 GHz RF band on this SSID.	5 GHz
5 GHz	Use the 5 GHz RF band on this SSID.	

### RTS/CTS Threshold

Setting	Description	Factory Default
32 to 2346 bytes	Specify the RTS/CTS threshold for the SSID.	2346

### Transmission Rate: 5 GHz/2.4 GHz

#### Data Transmission Rate

Setting	Description	Factory Default
Auto	The AWK Series will automatically sense the speed of the connected device(s) and adjust the data rate accordingly.	Auto

#### Minimum Data Transmission Rate

Setting	Description	Factory Default
0 to 65 Mbps (0 to disable)	Specify a minimum transmission rate. By setting a minimum transmission rate, the AWK Series will avoid communicating over weak signal wireless links to maintain better wireless performance and optimize the wireless frequency usage.	0 (Disabled)

#### Broadcast/Multicast Data Transmission Rate


Setting	Description	Factory Default
HT-MCS0 to HT-MCS15	Set the broadcast/multicast data transmission rate for the AWK.	HT-MCS15

### Management Transmission Rate

Setting	Description	Factory Default
HT-MCS0 to HT-MCS15	Set the management transmission rate for the AWK.	HT-MCS5

When finished, click **NEXT**.

### Configure SSID Settings



2

SSID Broadcast Status \*

Enabled ▼

Security \*

WPA2 ▼

WPA Mode \*

Personal ▼

Protected Management Frame \*

Disabled ▼

Encryption \*

AES ▼

EAPOL Version \*

1 ▼

Passphrase \*

..... 🗑️

At least 8 characters    8 / 64

Key Renew \*

3600

60 - 86400                      sec.

Copy Configurations to SSIDs ▼ i

BACK
CONFIRM

### SSID Broadcast Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable broadcasting the SSID. If enabled, wireless clients will be able to see and connect to this SSID.	Enabled (depending on the settings on the previous page)

### Security

Setting	Description	Factory Default
Open	Disable security on the SSID. This is not recommended.	Open
WPA	Use WPA authentication.	
WPA2	Use WPA2 authentication. This mode supports IEEE 802.11i with TKIP/AES + 802.1X encryption.	
WPA3	Use WPA3 authentication. This mode supports SAE (Simultaneous Authentication of Equals) to avoid network attacks, such as KRACK.	
WPA/WPA2 Mixed	Use WPA/WPA2 Mixed authentication. This allows both WPA and WPA2 clients to connect to the AWK.	
WPA2/WPA3 Mixed	Use WPA/WPA3 Mixed authentication. This allows both WPA2 and WPA3 clients to connect to the AWK.	

The AWK Series provides various standardized wireless security modes: **Open**, **WPA** (Wi-Fi Protected Access), **WPA2**, and **WPA3**.

- **Open:** No authentication, no data encryption.

- **WPA/WPA2-Personal:** Also known as WPA/WPA2-PSK. You will need to specify the Pre-Shared Key in the Passphrase field, which will be used by the TKIP or AES engine as a master key to generate keys that encrypt outgoing packets and decrypt incoming packets.
- **WPA3-Peronal:** Provide a more secured data connection than WPA2 by using SAE (Simultaneous Authentication of Equals).
- **WPA/WPA2-Enterprise:** Also called WPA/WPA2-EAP (Extensible Authentication Protocol). In addition to device-based authentication, WPA/WPA2-Enterprise enables user-based authentication via IEEE 802.1X. When the Enterprise is selected as the WPA Mode, an additional EAP protocol drop-down field will appear, allowing you to select TLS, TTLS, or PEAP. The EAP-TLS option supports TLS certificates and password upload interface.
- **WPA/WPA2 Mixed:** The AWK supports WPA/WPA2 at the same time. The AWK is able to authenticate with both Wi-Fi clients that use WPA and WPA2.
- **WPA2/WPA3 Mixed:** The AWK supports WPA2/WPA3 at the same time. The AWK is able to authenticate with both Wi-Fi clients that use WPA2 and WPA3.

When using any security mode except **Open**, configure the following settings.

#### **Protected Management Frame**

Setting	Description	Factory Default
Disabled	Disable the protected management frame. This option is not available when using WAP3.	Disabled
802.11w	Use 802.11w protocol as the protected management frame.	

#### **WPA Mode**

Setting	Description	Factory Default
Personal	Authenticate WPA, WPA2, and WPA3 with a Pre-shared Key (PSK).	Personal
Enterprise	Authenticate WPA, WPA2, and WPA3 with EAP security protocol.	

#### **Encryption**

Setting	Description	Factory Default
AES	Use Advance Encryption System (AES) encryption.	TKIP/AES Mixed
TKIP/AES Mixed*	Use TKIP/AES Mixed encryption. This option provides a TKIP broadcast key and TKIP+AES unicast key to support legacy AP clients. This option is rarely used and is not available when using WAP3.	

*\*This option is available for legacy mode in AP/Master only and does not support AES-enabled clients.*

#### **EAPOL Version**

If you selected AES encryption in AP mode, select the EAPOL version.

Setting	Description	Factory Default
1	Use EAPOL Version 1 as the security authentication method.	1
2	Use EAPOL Version 2 as the security authentication method.	

#### **Primary/Secondary RADIUS Server IP (for Enterprise mode only)**

Setting	Description	Factory Default
IP address	Specify the RADIUS authentication server for EAP.	None

#### **Primary/Secondary RADIUS Port (for Enterprise mode only)**

Setting	Description	Factory Default
0 to 65535	Specify RADIUS server port number.	1812

#### **Primary/Secondary RADIUS Shared Key (for Enterprise mode only)**

Setting	Description	Factory Default
0 to 128 characters	Enter the secret key shared for communication between AP and the RADIUS server. The key cannot contain the following special characters: ` ' "   ; & \$	None

### Passphrase (for Personal mode only)

Setting	Description	Factory Default
8 to 63 characters	Enter the passphrase. This is the master key to generate keys for encryption and decryption. The passphrase cannot contain the following special characters: ` ' "   ; & \$ Check Show Password to display the password in clear text.	None

### Key Renew

Setting	Description	Factory Default
60 to 86400 seconds (1 minute to 1 day)	Specify the interval at which the group key is renewed.	3600 (seconds)

### Copy Configurations to SSIDs

Setting	Description	Factory Default
SSID	Select a target SSID from the drop-down menu to copy the current configuration to.	None




## WARNING

The Open mode does not feature any form of authentication and data encryption. For security reasons, we highly recommend NOT to use Open as the security mode.


When finished, click **CREATE** to add a new SSID.





## Edit an Existing SSID

To edit an existing SSID, click the **Edit**  icon next to the SSID you want to edit. Refer to **Create a New SSID** for more information about setting.

SSID Settings ^


Some of SSIDs do not apply security type. We recommend disabling them.

 Q Search

	SSID	RF Band	Security	Encryption	Status
<input checked="" type="checkbox"/>	 MoxaGuest_5G	5 GHz	OPEN	---	Enabled
<input type="checkbox"/>	 Moxa-5G	5 GHz	WPA2 (Personal)	AES	Disabled
<input type="checkbox"/>	 Moxa-2G	2.4 GHz	WPA2 (Personal)	AES	Disabled


Max 9





## Delete an Existing SSID

To delete an existing SSID, check the SSID, then click the **Delete**  icon above the table.

SSID Settings ^

Some of SSIDs do not apply security type. We recommend disabling them.

 🔍 Search

	SSID	RF Band	Security	Encryption	Status
<input checked="" type="checkbox"/> 	MoxaGuest_5G	5 GHz	OPEN	---	Enabled
<input type="checkbox"/> 	Moxa-5G	5 GHz	WPA2 (Personal)	AES	Disabled
<input type="checkbox"/> 	Moxa-2G	2.4 GHz	WPA2 (Personal)	AES	Disabled

Max 9

When prompted, click **DELETE**.

**Delete SSID**

Are you sure you want to delete the selected ssid?

CANCEL
DELETE

## RF Settings

When selecting any operation mode, configure the following RF settings.



### NOTE

Available RF settings depend on which Operation mode is active: AP, Master, Client, Client-Router, Sniffer, or Slave mode.

#### RF Settings ^

##### 5 GHz

RF Type \*

N/AC/AX Mixed

Channel Width \*

20/40/80 MHz

Channel \*

36 (5180 MHz)

Bonded Channel(s)

40, 44, 48

Antenna \*

All

Max. Transmission Power \*

18

Antenna Gain \*

2

1 - 18

dBm

0 - 18

dBi

Beacon Interval \*

100

40 - 1000 ms.

##### 2.4 GHz

RF Type \*

B/G/N/AX Mixed

Channel Width \*

20/40 MHz

Channel \*

6 (2437 MHz)

Bonded Channel(s)

10

Antenna \*

All

Max. Transmission Power \*

18

Antenna Gain \*

2

1 - 18

dBm

0 - 18

dBi

Beacon Interval \*

100

40 - 1000 ms.

#### Advanced Settings ^

MTU \*

1500

576 - 2290 bytes

APPLY

## For 2.4 GHz

Configure the following settings:

### RF Type

Setting	Description	Factory Default
G/N/AX Mixed	Enable IEEE 802.11g/n/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	B/G/N/AX Mixed
B/G/N/AX Mixed	Enable IEEE 802.11b/g/n/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	
N/AX Mixed	Enable IEEE 802.11n/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	
AX Only	Only enable IEEE 802.11ax.	

### Channel Width (for 802.11n RF types only)

Setting	Description	Factory Default
20 MHz	Set the channel width to 20 MHz. If you are not sure which option to use, select 20/40 MHz.	20/40 MHz
20/40 MHz	Set the channel width to 20/40 MHz. This is recommended.	

### Channel

Setting	Description	Factory Default
1 (2412 MHz) to 11 (2462 MHz) / 13 (2472 MHz)	Select the channel from the drop-down list. Each channel supports different frequencies. <b>Note:</b> Available channels depend on the selected country.	6 (2437 MHz)

### Bonded Channel

Setting	Description	Factory Default
10 (read only)	The bonded channel used by the AP will be shown here if channel width is set to 20/40 MHz.	10

### Antenna

Setting	Description	Factory Default
1	Specify antenna 1 as the output antenna port.	All
2	Specify antenna 2 as the output antenna port.	
ALL	Specify both antennas as the output antenna port.	

### Maximum Transmission power

Setting	Description	Factory Default
dBm	Specify the maximum transmission power which acts as a hard ceiling for different transmission rates.	18 dBm

### Antenna Gain

Setting	Description	Factory Default
0 to 18 (dBi)	Specify the antenna gain.	2

### Beacon Interval

Setting	Description	Factory Default
40 to 1000 (ms.)	Specify the interval at which a beacon is sent.	100 (ms)

## For 5 GHz

Configure the following settings:

### RF Type: 5 GHz

Setting	Description	Factory Default
AC/AX Mixed	Enable IEEE 802.11ac/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	A/N/AC/AX Mixed



Setting	Description	Factory Default
N/AC/AX Mixed	Enable IEEE 802.11n/ac/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	
A/N/AC/AX Mixed	Enable IEEE 802.11a/n/ac/ax. Higher speed Wi-Fi clients may operate at slower speed if legacy Wi-Fi clients are connected to the network.	
AX Only	Only enable IEEE 802.11ax.	

#### **Channel Width (for any 11N RF type only)**

Setting	Description	Factory Default
20 MHz	Set the channel width to 20 MHz. If you are not sure which option to use, select 20/40 MHz.	20/40/80 MHz
20/40 MHz	Set the channel width to 20/40 MHz. This is recommended.	
20/40/80 MHz	Set the channel width to 20/40/80 MHz. If you are not sure which option to use, select 20/40 MHz.	

#### **Channel**

Setting	Description	Factory Default
36 (5180 MHz) to 165 (5825 MHz)	Select the channel from the drop-down list. Each channel supports different frequencies.	36 (5180 MHz)

#### **Bonded Channel**

Setting	Description	Factory Default
40/44/48 (read only)	The bonded channel used by the AP will be shown here if channel width is set to 20/40/80 MHz.	40/44/48

#### **Antenna**

Setting	Description	Factory Default
ALL	Specify both antennas as the output antenna port.	All
1	Specify antenna 1 as the output antenna port.	
2	Specify antenna 2 as the output antenna port.	

#### **Maximum Transmission power**

Setting	Description	Factory Default
dBm	Specify the maximum transmission power which acts as a hard ceiling for different transmission rates. <b>Note:</b> The supported Maximum Transmission Power depends on the selected country code.	18 dBm

#### **Antenna Gain (for AP/Master mode only)**

Setting	Description	Factory Default
0 to 18 (dBi)	Specify the antenna gain.	2

#### **Beacon Interval (for AP/Master mode only)**

Setting	Description	Factory Default
40 to 1000 (ms)	Specify the interval at which a beacon is sent.	100 (ms)

When finished, click **APPLY**.

## **Advanced RF Settings**

Some operation modes require additional advanced RF settings.



### **NOTE**

Available RF settings depend on which Operation mode is active.

Advanced Settings ^

MTU \*  
1500

68 - 2290 bytes

RTS / CTS Threshold \*  
2346

32 - 2346 bytes

Transmission Rate: 5 GHz

Data Transmission Rate \*      Min. Data Transmission Rate \*  
Auto      0

0 - 65 Mbps

Management Transmission Rat...  
HT-MCS5

Configure the following settings:

**MTU**

Setting	Description	Factory Default
576 to 2290 bytes	Configure the Maximum Transmission Unit (MTU) size (in bytes) depending on the application traffic type. Configuring a larger MTU value results in a lower packet count (less network congestion) over the wireless network when transmitting applications generate large data packets.	1500

**RTS/CTS Threshold (Client, Client-Router, Slave Mode Only)**

Setting	Description	Factory Default
32 to 2346 bytes	Specify the RTS/CTS threshold for the SSID.	2346

**Transmission Rate: 5 GHz/2.4 GHz (Client, Client-Router, Slave Mode Only)**

**Data Transmission Rate**

Setting	Description	Factory Default
Auto	The AWK Series will automatically sense the speed of the connected device(s) and adjust the data rate accordingly.	Auto

**Minimum Data Transmission Rate**

Setting	Description	Factory Default
0 to 64 Mbps (0 to disable)	Specify a minimum transmission rate. By setting a minimum transmission rate, the AWK Series will avoid communicating over weak signal wireless links to maintain better wireless performance and optimize the wireless frequency usage.	0 (Disabled)

**Management Transmission Rate**

Setting	Description	Factory Default
HT-MCS0 to HT-MCS15	Set the management transmission rate for the AWK.	HT-MCS5

When finished, click **APPLY**.

**MAC Cloning Settings (Client, Client-Router, Slave Mode Only)**

Enabling this feature allows the AWK client to copy the MAC address of the equipment connected to the LAN. This overcomes the limitation of the IP-Bridged behavior in a MAC-sensitive network (MAC-based communication or MAC-authenticated network).

## Wireless Settings

General
MAC Cloning
Wi-Fi Connections

MAC Cloning Status \*  
Enabled ▼

MAC Cloning Method \*  
Auto ▼

MAC Cloning Interface \*  
LAN 1 ▼

APPLY

Configure the following settings:

### **MAC Cloning Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the MAC Cloning function.	Disabled

### **MAC Cloning Method**

Setting	Description	Factory Default
Auto	The AWK client copies the MAC address of the device connected to the LAN if only one device is connected to AWK.	Auto
Static	The AWK client shares the assigned MAC address with multiple devices connected to the LAN. This allows for multiple devices to connect to the AWK via the LAN and only one of them needs to be assigned a MAC address.	

### **MAC Cloning Interface**

Setting	Description	Factory Default
LAN 1 (AWK-1161C)	Specify the static MAC address of LAN 1 that the connected AWK devices should copy.	LAN 1
LAN 1 to 5 (AWK-1165C)	Specify the static MAC address of LAN port that the connected AWK devices should copy.	

When finished, click **APPLY**.

## Wi-Fi Connection Status

To view the Wi-Fi connection status, click **Wi-Fi Connections** tab. The information on this screen depends on the active operation mode. The following view is from AP Mode.

### Wireless Settings

General | **Wi-Fi Connections**


**AP**

SSID  
AP: AWK-1161A-Machine


BSSID	Noise Floor	
46:90:E8:61:A1:12	-100 dBm	
Channel	Bonded Channel	Channel Width
36 (5180 MHz)	40, 44, 48	20/40/80 MHz

Select the SSID from the drop-down list to view its current status. In AP Mode, you can also view the client list to see all the connected client devices.

Associated Client List



MAC Address	IP Address	Conn. Duration	VHT Cap.	Tx. Rate (Mbps)	Chan. Width (MHz)	Mgmt. SNR. (dB)	Mgmt. SS. (dBm)	Mgmt. Tx. Pkt.
[Empty table body]								

Click the **Filter**  icon to select the information items that you want to show.



- MAC Address
- IP Address
- Connection Duration
- VHT Capability
- Transmission Rate


For the Client, Client-Router, and Slave operation modes, this view displays the SSID the device is associated with, and the properties of the connection.

### Wireless Settings

General    MAC Cloning    **Wi-Fi Connections**

---


**Client** 2024-04-12 12:12:46  

SSID	MAC Address	Current BSSID	AP IP Address
<b>.M-Guest</b>	<b>00:90:E8:00:00:01</b>	<b>00:4E:35:A1:64:B1</b> 	---
Channel	Bonded Channel	Channel Width	
<b>48 (5240 MHz)</b>	<b>44</b>	<b>20/40 MHz</b>	
Connection Duration	AP Has VHT Capacity		
<b>0d0h0m29s</b>	<b>No</b>		
Transmission Rate	Mgmt. SNR	Signal Strength	Noise Floor
<b>240 Mbps</b>	<b>56 dB</b>	<b>-42 dBm</b>	<b>-98 dBm</b>
Mgmt. Tx. Packets	Mgmt. Rx. Packets		
<b>3</b>	<b>279</b>		
Data Tx. Packets	Data Rx. Packets		
<b>5</b>	<b>2</b>		

# Connection Management


## Connection Check and Recovery

The **Connection Check and Recovery** tab contains Wi-Fi connectivity tools to define conditions of normal operational criteria and enable recovery attempts without human intervention. Click **Connection Check and Recovery** under **Wi-Fi** in the function tree to access this screen.



### Client-to-AP Link Check

When enabled, this recovery mechanism is triggered when the connection to the AP is lost. When disconnected, the device will reset the Wi-Fi interface in an attempt to recover the connection to the AP. If the connection can still not be recovered after the specified number of retries, the client will reboot and check the connectivity status again.



Configure the following settings:

#### **Client-to-AP Link Check Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Client-to-AP Link Check function.	Disabled

### Check Timeout

Setting	Description	Factory Default
10 to 60 (sec.)	Specify the check timeout interval.	30

### Reset Connection Recovery

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Reset Connection Recovery function.	Enabled

### Reset Connection Retry Count

Setting	Description	Factory Default
1 to 5	Specify the maximum number of times the device will reset the Wi-Fi interface to attempt to recover the connection.	5

### Reboot Recovery

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Reboot Recovery function.	Disabled

### Reboot Retry Count

Setting	Description	Factory Default
1 to 5	Specify the maximum number of times the device will reboot to attempt to recover the connection.	5

When finished, click **APPLY** to save your settings.

## AP Alive Check

This is a recovery mechanism which checks whether it is still possible to receive data frame from the connected AP. When the timeout is triggered, the client will send a null data packet to probe the AP it is connected to. If the AP does not respond after the specified number of retries, the client will begin scan for other AP candidates in order to recover network communications as quickly as possible.

### AP Alive Check

AP Alive Check Status ▼  
Enabled ▼

---

Check Interval *	Retry Count *
50	3
20 - 1000	ms.
3 - 10	
Expiry *	
1000	
100 - 10000	ms.
Threshold Indicate *	
SNR <span>▼</span>	
5 GHz	2.4 GHz
SNR Candidate Threshold *	SNR Candidate Threshold *
40	40
5 - 60	dB
5 - 60	dB

Configure the following settings:

### AP Alive Check Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the AP Alive Check function.	Disabled

### **Check Interval**

Setting	Description	Factory Default
20 to 1000 (ms)	Specify the interval at which the device will probe the AP.	50

### **Retry Count**

Setting	Description	Factory Default
3 to 10	Specify the maximum number of times the device will probe the AP.	3

### **Expiry**

Setting	Description	Factory Default
100 to 10000 (ms.)	Specify the connection expiration interval (in ms). If exceeded, the client will consider the AP unreachable or unresponsive, and will trigger the recovery mechanism.	1000

### **Threshold Indicate**

Setting	Description	Factory Default
SNR	Use SNR as the threshold indicator.	SNR
Signal Strength	Use signal strength as the threshold indicator.	

### **5 GHz: SNR Candidate Threshold (for SNR)**

Setting	Description	Factory Default
5 to 60 (dB)	Specify the SNR roaming threshold.	40

### **2.4 GHz: SNR Candidate Threshold (for SNR)**

Setting	Description	Factory Default
5 to 60 (dB)	Specify the SNR roaming threshold.	40

### **5 GHz: Signal Strength Candidate Threshold (for Signal Strength)**

Setting	Description	Factory Default
-100 to -35 (dBm)	Specify the signal strength roaming threshold.	-65

### **2.4 GHz: Signal Strength Candidate Threshold (for Signal Strength)**

Setting	Description	Factory Default
-100 to -35 (dBm)	Specify the signal strength roaming threshold.	-65



## **NOTE**

The SNR and signal strength thresholds are used to determine when the AWK will start looking for a better AP to associate with. If the current connection quality to the AP (based on SNR or signal strength) is lower than the specified threshold value, the client will start looking for other suitable wireless devices.

When finished, click **APPLY**.

## **Remote Host Check**

When enabled, this recovery mechanism is triggered when IP traffic fails to reach the configured remote host. The mechanism works by checking if the remote host is reachable at the defined check interval. If the host is still unreachable after the specified number of retries, the client will disconnect from the current AP and will attempt to associate with another AP.



### Remote Host Check

Remote Host Check Status \*

Enabled ▼

---

Host Type \*

Static ▼ Host \*

---

Check Interval \* Check Timeout \*

30 1000

1 - 60 sec. 100 - 1000 ms.

Retry Interval \* Retry Count \*

1 5

1 - 30 sec. 1 - 5

APPLY

Configure the following settings.

#### **Remote Host Check Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Remote Host Check function.	Disabled

#### **Host Type**

Setting	Description	Factory Default
Static	Use Static as the host type.	Static
Dynamic	Use Dynamic as the host type.	

#### **Host (for Static Host Type only)**

Setting	Description	Factory Default
Host name	Specify the host name.	None

#### **Check Interval**

Setting	Description	Factory Default
1 to 60 (sec.)	Specify the interval at which the client will check the connection to the host.	30

#### **Check Timeout**

Setting	Description	Factory Default
100 to 10000 (ms)	Specify the connection expiration interval (in ms). If exceeded, the client will consider the remote host unreachable or unresponsive and will trigger the recovery mechanism.	1000

#### **Retry Interval**

Setting	Description	Factory Default
1 to 30 (sec.)	Specify the interval at which the device will check the host again after a failed attempt.	1

#### **Retry Count**


Setting	Description	Factory Default
1 to 5	Specify the maximum number of times the device will check the host.	5

When finished, click **APPLY**.

## **AP-based Disconnection (AWK-1161A, AWK-1165A Only)**

The **AP-based Disconnection** tab contains Wi-Fi connectivity tools to configure the signal strength conditions for clients to meet normal operational communication requirements. Additionally, this screen

allows users to enable the AP-based disconnection mechanism to disconnect legacy clients without roaming logic in order to encourage these clients to automatically associate to another AP with a stronger signal when falling below the set threshold. Click the **AP-based Disconnection** tab under **Wi-Fi > Connection Management** in the function tree to access this screen.



This tab displays all configured SSID profiles on the device. Click the pencil icon next to an SSID to edit the disconnection criteria for legacy clients.

#### Edit AP-based Disconnection Settings

5 GHz: AWK-1161A-Machine Sta...  
 Enabled    
 Status \*  
 Enabled    
 Attempts \*  
 3   
 1 - 10  
 Indicator of Disconnection Threshold \*  
 SNR   
 5 GHz  
 Disconnection Threshold (SNR) \*  
 40

CANCEL APPLY

#### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the AP-based Disconnection mechanism.	Disabled

#### Attempts

Setting	Description	Factory Default
1 to 10	Specify the number of check attempts, with a 1 second interval between each check. If a client's SNR or signal strength falls below the set threshold consecutively for the specified number of attempts, the AP will disconnect the client.	3

#### Indicator of Disconnection Threshold

Setting	Description	Factory Default
SNR/Signal Strength	Select the threshold type for the disconnection mechanism.	SNR


### Disconnection Threshold

Setting	Description	Factory Default
5 to 60 dB for SNR/ -100 to -35 dBm for Signal Strength	Specify the threshold criteria for identifying poor client signal. When the client signal quality falls below the configured threshold, the AP will begin to check the client's signal. If a client's SNR or signal strength falls below the set threshold consecutively for the specified number of attempts, the AP will disconnect the client.	40 dB for SNR -65 dBm for Signal Strength

When finished, click **APPLY**.

## Link Fault Pass-through

The Link Fault Pass-through feature helps detect wired link faults on the device's local Ethernet interface, or in uplink paths to a wired remote host. If a link fault is detected, the AWK AP will automatically disable its AP or Master SSID service to prevent wireless clients from associating and connecting to an AP that cannot successfully link to the designated application or service on the wired LAN network.



### Local Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Link Fault Pass-through for local Ethernet interfaces.	Disabled

### LAN Port

Setting	Description	Factory Default
LAN port	Select the LAN interface to monitor.	LAN 1

### Remote Status

Enabling Fault Link Pass-through for remote links will cause the AWK to ping the target remote host at the specified interval to determine the status of the wired connection to the host.

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Link Fault Pass-through for links to remote hosts.	Disabled

**Remote**

Remote Status \*

Enabled ▼

---

Target \*

IPv4 Address/Host 0 / 60

Timeout \*

1000

100 - 1000 ms.

**Disconnection Detection**

Interval \*                      Retry Count \*

1    3

1 - 30                                      sec.    1 - 5

**Reconnection Detection**

Interval \*                      Retry Count \*

1    3

1 - 30                                      sec.    1 - 5

APPLY

**Target**

Setting	Description	Factory Default
IP address or hostname	Specify the IP address or hostname of the remote host to monitor.	None

**Timeout**

Setting	Description	Factory Default
100 to 1000 ms	Specify the duration (in ms) the AWK will wait before considering the host unresponsive.	1000

**Disconnection Detection**

The Disconnection Detection parameters determine the detection interval and retry count criteria for the AWK to deem the target remote host unreachable, triggering the shutdown of SSID service. The detection frequency may depend on the nature of the application and should be adjusted accordingly.

**Interval**

Setting	Description	Factory Default
1 to 30 sec	Specify the interval (in seconds) at which the AWK will ping the target host.	1

**Retry Count**

Setting	Description	Factory Default
3	Specify the number of times the AWK will retry to ping the host if no response is received.	3

**Reconnection Detection**

The Reconnection Detection parameters determine the detection interval and retry count criteria for the AWK to check if the link to the remote has been restored. If the link is deemed restored, the AWK will re-activate the SSID services for wireless clients attempting to connect to the AP.

### Interval

Setting	Description	Factory Default
1 to 30 sec	Specify the interval (in seconds) at which the AWK will ping the target host.	1

### Retry Count

Setting	Description	Factory Default
3	Specify the number of times the AWK will retry to ping the host if no response is received.	3

When finished, click **APPLY**.

## Roaming (AWK-1161C, AWK-1165C Only)

The **Roaming** page lets you enable or disable roaming functionality and configure roaming threshold settings. Click **Roaming** under **Wi-Fi** in the function tree to access this screen.

### Roaming

Client-Based Turbo Roaming  
Enabled

Indicator of Roaming Threshold \*  
SNR

5 GHz Roaming Threshold (SNR) * 40 5 - 60 dB	2.4 GHz Roaming Threshold (SNR) * 40 5 - 60 dB
---	---

Roaming Difference \*  
7  
5 - 30

**APPLY**

Configure the following settings:

#### Client-Based Turbo Roaming

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Client-based Turbo Roaming function.	Disabled

#### Indicator of Roaming Threshold

Setting	Description	Factory Default
SNR	Use SNR as the roaming threshold indicator.	SNR
Signal Strength	Use signal strength as the roaming threshold indicator.	

#### 5 GHz: Roaming Threshold (for SNR)

Setting	Description	Factory Default
5 to 60 (dB)	Specify the SNR roaming threshold. If the current connection quality is below this threshold, the client will start looking better signal AP to associate with.	40

#### 2.4 GHz: Roaming Threshold (for SNR)

Setting	Description	Factory Default
5 to 60 (dB)	Specify the SNR roaming threshold. If the current connection quality is below this threshold, the client will start looking better signal AP to associate with.	40

### 5 GHz: Roaming Threshold (for Signal Strength)

Setting	Description	Factory Default
-100 to -35 (dBm)	Specify the signal strength roaming threshold. If the current connection quality is below this threshold, the client will start looking better signal AP to associate with.	-65

### 2.4 GHz: Roaming Threshold (for Signal Strength)

Setting	Description	Factory Default
-100 to -35 (dBm)	Specify the signal strength roaming threshold. If the current connection quality is below this threshold, the client will start looking better signal AP to associate with.	-65

### Roaming Difference

Setting	Description	Factory Default
5 to 30	Specify the roaming difference value.	7



#### NOTE

The Roaming Threshold determines when clients will start background scanning for other candidate APs with a stronger signal. Once the AWK starts background scanning, the client will compare the connection quality of the current and candidate AP. If the difference is larger than the specified Roaming Difference, the client will roam to the new AP.



#### NOTE

While the AWK is scanning the background, it will allocate 1/3 of its RF resources to search for candidate APs based on the channel plan configured on the [Wi-Fi > Wireless Settings](#) page. The maximum background scanning time required is proportional to the number of channels checked in channel plan.



#### NOTE

Once the background scan successfully identifies a candidate AP, the device will roam. The typical Turbo Roaming handover time of < 150 ms is an average of all documented test results, in optimized conditions, across APs configured with interference-free RF channels, and default Turbo Roaming parameters. The clients were configured with 3-channel roaming at 100 Kbps traffic load. Other conditions and factors may affect actual roaming performance.



#### NOTE

As key renewal is automatic for WPA3 encryption, using Turbo Roaming with WPA3 will result in a one-time increased handover time of approximately 200 ms during the roaming process when the key renewal takes place.

When finished, click **APPLY**.

## Wi-Fi Security


The **Wi-Fi Security** page lets you configure the Client Isolation and Wi-Fi Access Control List functions to manage access to the AWK device. Click **Wi-Fi Security** under **Wi-Fi** in the function tree to access this screen.

### Client Isolation (AWK-1161A, AWK-1165A Only)

The AWK Series supports client isolation functionality for AP-based operation modes to provide an additional layer of security for connected client devices.

For configured virtual access points, select the SSID you wish to enable client isolation for. Client isolation can be either enforced based on SSID where clients connecting to the same SSID on the AP are isolated from each other; or enforced by subnet where clients connecting to the same subnet as the configured SSID will be isolated from each other.

By default, client isolation is not enforced.



## Wi-Fi ACL

The AWK Series supports Wi-Fi ACL filtering for both AP and client-based operation modes. Depending on the active operation mode, Wi-Fi ACL has two purposes. For AP-based operation modes, it blocks rogue client devices attempting to exhaust the Wi-Fi interface's resources. For client-based operation modes, it designates the list of authorized APs for the client to connect to.

There are two types of Wi-Fi ACL, Static or Automatic Wi-Fi ACL. Which type to use depends on the type of unwanted device to filter out through the Wi-Fi interface.

### Automatic Wi-Fi ACL (AWK-1161A, AWK-1165A Only)

Automatic Wi-Fi ACL will attempt to authenticate incoming device connections based on a specified number of tries. If the device fails all attempts, the AWK will automatically add this device to the list and block all future authentication requests from that device.



#### Automatic Wi-Fi ACL Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Automatic Wi-Fi ACL.	Disabled

#### Wi-Fi Authentication Failure Retry Threshold

Setting	Description	Factory Default
1 to 10	Specify the number of client authentication attempts. If the client consecutively fails the specified number of authentication checks, it will consider the client (client or AP) as a rogue device. Automatic Wi-Fi ACL will add the rogue device to the ACL and will block subsequent authentication attempts by this device in the future.	Empty



## NOTE

Only management accounts with "Network" authority can manually remove or unlock devices blocked via Automatic Wi-Fi ACL.

When finished, click **APPLY**.

## Static Wi-Fi ACL

Static Wi-Fi ACL allows users to manually add devices to the list by MAC address and set the access policy for all entries, either to allow or reject connections from the devices in the list.

### Static Wi-Fi ACL Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Static Wi-Fi ACL.	Disabled


### Static Wi-Fi ACL List Mode

Setting	Description	Factory Default
Block/Accept	Choose to either block or accept connections from the MAC addresses in the Static Wi-Fi ACL table.	Empty

When finished, click **APPLY**.

## Ports

From the **Ports** section, you can configure **Port Settings**.



## Port Settings

The **Ports Settings** page is used to configure the physical LAN 1 (AWK-1161C/A) or LAN 1 to 2 (AWK-1165C/A) network ports on the device. Click **Port Settings** under **Ports** in the function tree to access this screen.








## General Settings

Click **General** tab first, then click the **Edit**  icon on the port you want to configure.

### Port Settings

General

Port Status

	Port	Status	Description
	1	Enabled	
	2	Enabled	
	3	Enabled	
	4	Enabled	
	5	Enabled	

### Edit Port 1 Settings

Status  
Enabled ▼

Description

CANCEL
APPLY

Configure the following settings:

#### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the port.	Enabled



### ATTENTION

The AWK-1161C and AWK-1161A Series only has one LAN port (LAN1). If this port is disabled, the device will become inaccessible. The port can only be re-enabled via the console port or by resetting the device to factory default settings using the reset button.

#### Description

Setting	Description	Factory Default
0 to 127 characters	Enter a description for the port.	None

When finished, click **APPLY**.




### ATTENTION

When more than one LAN ports is enabled, only one LAN port should be used as an uplink. The other LAN ports may be used to connect other Ethernet based devices such as IP cameras. Be careful NOT to connect more than one LAN port as uplinks to a switch simultaneously to prevent switching loops.

## Status Check


Click the **Port Status** tab to check the current port and port link status.



Port	Status	Link Status
LAN 1	Enabled	Link Down
LAN 2	Enabled	Link Up

## Layer 2 Switching

This section describes how to configure the VLAN settings for the AWK.



## VLAN

### The Virtual LAN (VLAN) Concept

#### What is a VLAN?

A virtual LAN, commonly known as a VLAN, is a group of hosts with a common set of requirements that communicate as if they were connected to the same broadcast domain, regardless of their physical location. A VLAN has the same attributes as a physical LAN, but it allows for end stations to be grouped together even if they are not located on the same network switch. Network reconfiguration can be done through software instead of physically relocating devices.

VLANs now extend as far as the reach of the access point signal. Clients can be segmented into wireless sub-networks via SSID and VLAN assignment. A Client can access the network by connecting to an AP configured to support its assigned SSID/VLAN.

#### Benefits of VLANs

VLANs are used to conveniently, efficiently, and easily manage your network in the following ways:

- Manage additions, relocations, and changes from a single point of contact
- Define and monitor groups
- Reduce broadcast and multicast traffic to unnecessary destinations
- Improve network performance and reduce latency
- Increase security
- Secure network restricts members to resources on their own VLAN
- Clients roam without compromising security

## **VLAN Workgroups and Traffic Management**

The AP assigns clients to a VLAN based on a Network Name (SSID). The AP can support up to 9 SSIDs per radio interface, with a unique VLAN configurable per SSID.

The AP matches packets transmitted or received to a network name with the associated VLAN. Traffic received by a VLAN is only sent on the wireless interface associated with that same VLAN. This eliminates unnecessary traffic on the wireless LAN, conserving bandwidth and maximizing throughput.

In addition to enhancing wireless traffic management, the VLAN-capable AP supports easy assignment of wireless users to workgroups. In a typical scenario, each user VLAN represents a department workgroup; for example, one VLAN could be used for a marketing department and the other for a human resource department.

In this scenario, the AP would assign every packet it accepted to a VLAN. Each packet would then be identified as marketing or human resource, depending on which wireless client received it. The AP would insert VLAN headers or "tags" with identifiers into the packets transmitted on the wired backbone to a network switch.

Finally, the switch would be configured to route packets from the marketing department to the appropriate corporate resources such as printers and servers. Packets from the human resource department could be restricted to a gateway that allowed access to only the Internet. A member of the human resource department could send and receive e-mail and access the Internet but would be prevented from accessing servers or hosts on the local corporate network.

## Global Settings

The **Global Settings** page is used to configure the management VLAN and interface. Click the **Global** tab to access this screen.

### VLAN

Global
Settings

Management VLAN \*  
1

**Management Interface Quick Settings**  
 Management Interface \*  
LAN1 i

Mode \* Access    PVID \* 1    Tagged VLAN 1    Untagged VLAN 1

APPLY

Configure the following settings:

### Management VLAN ID

Setting	Description	Factory Default
1 to 4094	Specify the management VLAN of this AWK. By default, there is only VLAN ID 1. Additional VLAN IDs will need to be created first before they can be selected.	1

### Management Interface Quick Settings

#### Management Interface

Setting	Description	Factory Default
Interface	Select the management VLAN interface.	None

#### Mode

Setting	Description	Factory Default
Access	Access mode is used if the port is connected to a single device, without tags.	Access
Hybrid	Hybrid mode is used if the port is connected to another Access 802.1Q VLAN-aware switch or another LAN that combines tagged and untagged devices.	

#### PVID

Setting	Description	Factory Default
1 to 4094	Set the default VLAN ID for untagged devices connected to the port.	1

#### Tagged VLAN

Setting	Description	Factory Default
1 to 4094	If the port type is set to Trunk or Hybrid, specify the VLAN ID for tagged devices that connect to this port.	None


#### Untagged VLAN

Setting	Description	Factory Default
1 to 4094	If the port type is set to Hybrid, specify the VLAN ID for tagged devices that connect to this port and the tags that need to be removed in egress packets.	Dependent on the selected PVID

When finished, click **APPLY**.

## VLAN Settings


From the **Settings** tab, you can create, edit, and delete VLANs. Click the **Settings** tab to access this screen.




The screenshot shows the 'VLAN' settings page with the 'Settings' tab selected. At the top left, there are two tabs: 'Global' and 'Settings'. Below the tabs, there are two icons: a plus sign in a square and a grid icon. A table with the following columns is displayed: 'VLAN', 'Name', and 'Member Interface'. The table contains one entry with '1' in the 'VLAN' column and 'LAN1, LAN2' and 'SSID: Moxa\_Guest' in the 'Member Interface' column. Below the table, there is a 'Max 256' label.


VLAN	Name	Member Interface
1		LAN1, LAN2 SSID: Moxa_Guest

### Create a New VLAN ID

To add a new VLAN ID, click the **Add**  icon.



This screenshot is identical to the previous one, but the plus sign icon in the top left is highlighted with a red square, indicating it is the button to click to add a new VLAN.



The 'Create VLAN' dialog box has a title 'Create VLAN' in teal. It contains two input fields: 'VLAN ID \*' with a value of '1' and a range of '1 - 4094', and 'Name' with a value of '0 / 32'. An information icon (i) is next to the 'VLAN ID \*' field. At the bottom right, there are two buttons: 'CANCEL' and 'CREATE'.

Configure the following settings:

#### VLAN ID

Setting	Description	Factory Default
1 to 4094	Enter the VLAN ID.	None

#### Name

Setting	Description	Factory Default
0 to 32 characters	Enter a name for the VLAN.	None

When finished, click **CREATE**.

## Edit an Existing VLAN ID

To edit an existing VLAN ID, click the **Edit**  icon next to the VLAN you want to edit.

<input type="checkbox"/>	VLAN	Name	Member Interface
<input type="checkbox"/>	1		LAN1, LAN2 SSID: Moxa_Guest

Max 256

Configure the following settings:



### NOTE

Once created, the VLAN ID cannot be changed. Only the VLAN name can be edited.

To modify a VLAN ID and VLAN name combination, delete the entry and create a new entry with the desired VLAN ID and name.




#### Name

Setting	Description	Factory Default
0 to 32 characters	Enter a name for the VLAN ID.	None

When finished, click **APPLY**.

## Edit VLAN Interface Settings

To edit the VLAN interface settings, click the **Edit**  icon next to the interface you want to edit.

Interface	Mode	PVID	Untagged VLAN
 LAN1	Access	1	1
 LAN2	Access	1	1
 SSID: .M-Guest	Access	1	1

## Edit Interface LAN1 Settings

Mode\*  
 Access ▼

---

PVID\*  
 1 ▼

---

Tagged VLAN  
 ..... ▼

---

Untagged VLAN  
 1 ▼

---

Copy Configurations to Interfaces ▼ ⓘ

CANCEL

APPLY

Configure the following settings.

### Mode

Setting	Description	Factory Default
Access	Access mode is used if the port is connected to a single device, without tags.	Access
Hybrid	Hybrid mode is used if the port is connected to another Access 802.1Q VLAN-aware switch or another LAN that combines tagged and untagged devices.	

### PVID

Setting	Description	Factory Default
1 to 4094	Set the default VLAN ID for untagged devices connected to the port.	1

### Tagged VLAN

Setting	Description	Factory Default
1 to 4094	If the port type is set to Hybrid, specify the VLAN ID for tagged devices that connect to this port.	None

### Untagged VLAN

Setting	Description	Factory Default
VID range from 1 to 4094	If the port type is set to Hybrid, specify the VLAN ID for tagged devices that connect to this port and the tags that need to be removed in egress packets.	1

### Copy Configurations to Interfaces

Setting	Description	Factory Default
Interface	Select the interface to copy the configuration of this interface to.	None

When finished, click **APPLY**.

# IP Configuration

The **IP Configuration** section is used to configure the device's basic IP configuration. Click **IP Configuration** in the function tree.

## General Settings

The **General** tab lets you configure the device's basic network information. Click the **General** tab to access this screen.

The screenshot shows the 'IP Configuration' screen with the 'General' tab selected. Under the 'LAN' section, the 'IP Mode' is set to 'Static'. The 'IP Address \*' field contains '192.168.127.253', the 'Subnet Mask \*' field contains '24 (255.255.255.0)', and the 'Default Gateway' field is empty. There are also empty fields for 'DNS Server 1' and 'DNS Server 2'. An 'APPLY' button is located at the bottom left of the form.

Configure the following settings.

### IP Mode

Setting	Description	Factory Default
DHCP	The AWK is assigned an IP address automatically by the network's DHCP server.	Static
Static	Manually configure up the AWK's IP address.	

### IP Address

Setting	Description	Factory Default
IP address	Enter the AWK's IP address.	192.168.127.253

### Subnet mask

Setting	Description	Factory Default
Subnet mask	Select the subnet mask. This is used to identify the type of network the AWK is connected to (e.g., 255.255.0.0 for a Class B network, or 255.255.255.0 for a Class C network).	24 (255.255.255.0)

### Default Gateway

Setting	Description	Factory Default
IP address	Enter the IP address of the router that connects the LAN to an outside network.	None

### DNS Server 1 and DNS Server 2

Setting	Description	Factory Default
IP address	Enter the primary and secondary DNS server address. After entering the DNS server's IP address, you can input the AWK's URL (e.g., http://ap11.abc.com) in your browser's address field instead of entering the IP address. The Secondary DNS server will be used if the Primary DNS server fails to connect.	None

When finished, click **APPLY**.



# IPv6

In addition to other benefits, IPv6 offers a significantly larger addressing pool compared to IPv4. IPv6 addresses are represented as eight groups of four hexadecimal digits each, separated by colons. The full representation may be shortened; for example, 2001:0db8:0000:0000:0000:8a2e:0370:7334 becomes 2001:db8::8a2e:370:7334.

The AWK-1160A and AWK-1160C Series support an IPv4 and IPv6 dual stack design, allowing the device to configure both an IPv4 and IPv6 address. This feature also allows the AWK to communicate with other nodes on the LAN or the Internet using either IPv4 or IPv6. The DNS protocol is used by both IP protocols to resolve fully qualified domain names and IP addresses, but dual stack requires that the resolving DNS server can resolve both types of addresses.


The IPv6 configuration options vary depending on the model and operation mode configured on the AWK-1160 Series device.

- **LAN:** All operation modes except Client-router mode.
- **WAN:** Client-router mode only.

Refer to the following sections for more information on the available modes for each option.

## IPv6 LAN Options

In all operation modes except Client-router mode, the AWK acts as a bridge device that receives and transmits data within the same network segment.



### IPv6 Mode

Setting	Description	Factory Default
Disabled	Disable IPv6 functionality.	Disabled
Static	Manually configure the device's IPv6 address information. requires manual configuration.	
Dynamic	Automatically acquire the IPv6 address and DNS server information from an upstream IPv6 DHCP server on the network.	

If **IPv6 Mode** is set to **Static**, configure the following options:

IPv6 Mode \*  
 Static

---

IPv6 Address \* Prefix Length \*

Required 0 - 128

IPv6 Gateway

---

IPv6 DNS Server 1 IPv6 DNS Server 2

---

APPLY

### IPv6 Address

Setting	Description	Factory Default
IPv6 address	Specify the IPv6 in the format of the eight groups of four hexadecimal digits, For example: 2001:b011:20e0:cb8:211:32ff:fe88:1d16	None

### Prefix Length

Setting	Description	Factory Default
0 to 128 characters	Specify the IPv6 Prefix Length, between 0 to 128 characters. This is equivalent to the IPv4 subnet mask.	None

### IPv6 Gateway

Setting	Description	Factory Default
IPv6 gateway address	Specify the IPv6 gateway address, if applicable.	None

### IPv6 DNS Server 1/2

Setting	Description	Factory Default
DNS server address	Specify the address of the primary and secondary IPv6 DNS server.	None

## IPv6 WAN Options

When operating in Client-router mode, the AWK acts as a router interfacing between two different network segments. Note that, except for Static, all WAN options require the admin to first configure the LAN IPv6 address in the Client operation mode and then switch back to Client-router mode in order to apply settings for the Dynamic, Relay, and DHCPv6-PD options.

**IP Configuration**

General | IPv6 | Status

Disabled

Static

Dynamic

Relay

DHCPv6-PD

Prefix Length \*  
0 - 128

IPv6 DNS Server 1 IPv6 DNS Server 2

APPLY

### IPv6 Mode

Setting	Description	Factory Default
Disabled	Disable IPv6 functionality.	Disabled
Static	Manually configure the device's IPv6 address information. requires manual configuration.	
Dynamic	Automatically acquire the IPv6 address and DNS server information from an upstream IPv6 DHCP server on the network.	
Relay	Configure the AWK as an IPv6 client and relay agent that can relay DHCPv6 requests from LAN-connected IPv6 clients to an upstream DHCPv6 Server. In this mode, the AWK automatically acquires its IPv6 address and DNS server information from an upstream IPv6 DHCP server on the network.	
DHCPv6-PD	Configure the AWK as an IPv6 client and prefix delegator that can automatically delegate IPv6 prefixes and assign IP addresses to connected devices based on the DHCPv6 Server configuration. In this mode, the AWK automatically acquires its IPv6 address and DNS server information from an upstream IPv6 DHCP server on the network.	

If **IPv6 Mode** is set to **Static**, configure the following options:

IPv6 Mode \*  
Static

IPv6 Address \*  
Required

Prefix Length \*  
0 - 128

IPv6 Gateway

IPv6 DNS Server 1

IPv6 DNS Server 2

APPLY

### IPv6 Address

Setting	Description	Factory Default
IPv6 address	Specify the IPv6 in the format of the eight groups of four hexadecimal digits, For example: 2001:b011:20e0:cb8:211:32ff:fe88:1d16	None

### Prefix Length

Setting	Description	Factory Default
0 to 128 characters	Specify the IPv6 Prefix Length, between 0 to 128 characters. This is equivalent to the IPv4 subnet mask.	None

### IPv6 Gateway

Setting	Description	Factory Default
IPv6 gateway address	Specify the IPv6 gateway address, if applicable.	None

### IPv6 DNS Server 1/2

Setting	Description	Factory Default
DNS server address	Specify the address of the primary and secondary IPv6 DNS server.	None

# IP Configuration Status

To view the status of the current IP configuration, click the **Status** tab.

**IP Configuration**

General IPv6 **Status**

**LAN**

IP Mode  
**Static**

IP Address: 192.168.127.253      Subnet Mask: 255.255.255.0      Default Gateway: ---

DNS Server 1: ---      DNS Server 2: ---

IP Conflict Check  
**Pass**

IPv6 Mode  
**Static**

IPv6 Address: 2001:b011:20e0:cb8:211:32ff:fe88:1d16/64

IPv6 Default Gateway: ---

IPv6 DNS Server 1: ---      IPv6 DNS Server 2: ---

# Network Service

From the **Network Service** section, you can configure **DHCP Server** and **DHCPv6 Server** settings.

**Network Service**

DHCP Server

DHCPv6 Server

## DHCP Server

The **DHCP Server** section is used for configuring a local DHCP server for IP provisioning to connected devices. DHCP Server is only available for AP/Master/Client-Router operation modes. If the device is in Client-Router mode, the DHCP service applies to LAN interfaces for wired connected devices.

IP addresses can be assigned in one of two ways:

- **Dynamic:** The DHCP server automatically assigns IP addresses to devices from a configured IP address range.
- **Static:** Users manually map an IP address to a specific MAC address.

If necessary, users can use a mixed provisioning model with both dynamic DHCP pool and MAC-based IP assignment. In a mixed DHCP mode environment, the system will first check if the device is listed in the MAC-based IP assignment table. If no matching entry is found, the system will assign an IP address from the configured DHCP IP pool.



### NOTE

Due to a functional limitation, if the device's own IP is acquired through DHCP, the DHCP Server feature cannot be enabled on the device.

**DHCP Pool** ^

Status \*  
Enabled

IP Address : Start \* 192.168.127.59      IP Address : End \* 192.168.127.77

**MAC-based IP Assignment** ^

+ Search

<input type="checkbox"/>	Hostname	MAC Address	IP Address	Status
Max 32 <span style="float: right;">0 of 0</span>				


APPLY

## DHCPv6 Server

### General

The DHCPv6 Server feature allows the device to assign IPv6 address to connected devices.

If the AWK's IPv6 settings were manually configured or obtained via DHCPv6-PD, the AWK can provision IPv6 addresses to connected devices downstream of the AWK's LAN ports in one of three supported modes.



#### DHCPv6 Server Mode

Setting	Description	Factory Default
Disabled	Disable the DHCPv6 server function.	Disabled
SLAAC + RDNSS	Connected devices or IPv6 clients issue a Router Solicitation (RS) and interpret the IPv6 Prefix, Default Gateway, DNS address from the Router Advertisement (RA) to compose their IPv6 address parameters by combining the prefix with a self-generated host ID.	
Stateless DHCPv6	Connected devices or IPv6 clients issue Router a Solicitation (RS) and interpret the IPv6 Prefix, Default Gateway from the Router Advertisement (RA) to compose their IPv6 address parameters by combining the prefix with a self-generated host ID. Subsequently it issues a DHCP Solicit and interprets the DHCPv6 Advertise to extract the DNS address.	


Stateful DHCPv6	Connected devices or IPv6 clients issue a Router Solicitation (RS) and interpret the Default Gateway address from the Router Advertisement (RA). Subsequently, it issues a DHCP Solicit / Request and interprets the DHCPv6 Advertise / Reply respectively to extract the DNS address and issued IPv6 address. The benefit of the Stateful DHCPv6 option is the state of all issued IPv6 address can be monitored and managed in the DHCPv6 Server.	
-----------------	---	--

#### Lease Time


Setting	Description	Factory Default
2 to 14400	Specify the valid duration (in minutes) of issued IPv6 addresses.	1440

#### DNS Server 1/2

Setting	Description	Factory Default
IP address	Specify the IP address of the first and second DNS server.	None

If **Stateful DHCPv6** is selected, configure the IPv6-to-MAC mapping. Click the **Add**  icon to add a new entry.

MAC-based IPv6 Assignment ^

 Q Search

<input type="checkbox"/>	Hostname	MAC Address	IPv6 Suffix	Status

Max 32 0 of 0

## Lease Table

The **Lease Table** page shows the IPv6 addresses assigned by the DHCPv6 Server.

**DHCPv6 Server**


General **Lease Table**

  Q Search

Hostname	MAC Address	IPv6 Address	Time Left


Items per page: 50 0 of 0 |< < > >|

Click the **Refresh**  icon to refresh the table.

Click the **Export**  button to export the table.

## Routing and NAT

From the **Routing and NAT** section you can configure **Routing** and **NAT** settings.


 **Routing and NAT** ^

Routing v

NAT

# Routing

The **Routing** section is used for managing static routes and checking the routing table.





## Unicast Route

### Static Route Settings

You can create, edit, and delete static route entries from the **Static Route** page. Click **Static Route** under **Routing > Unicast Route** in the function tree.

#### Create a New Static Route

Click the **Add**  icon to create a new entry.



### Create Static Route Entry

Entry Status \*  
 Disabled ▾

Name  
 \_\_\_\_\_  
 0 / 31

Destination \*  
 \_\_\_\_\_

Netmask \*  
 24 (255.255.255.0) ▾

Next Hop  
 \_\_\_\_\_

Interface \*  
 WAN ▾

Metric  
 1 - 32766

CANCEL CREATE

Configure the following settings:

**Entry Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the static route entry.	Disabled

**Name**

Setting	Description	Factory Default
0 to 31 characters	Enter a name for the static route entry.	None

**Destination**

Setting	Description	Factory Default
IP address	Specify the destination IP address.	None

**Netmask**

Setting	Description	Factory Default
IP address	Specify the subnet mask for this IP address.	24 (255.255.255.0)

**Next Hop**

Setting	Description	Factory Default
IP address	Specify the next gateway IP address. This IP address should be in the same subnet as the specified interface.	None

**Interface**

Setting	Description	Factory Default
Interface	Select the network interface for this route.	WAN

**Metric**

Setting	Description	Factory Default
1 to 32766	Specify the cost metric this route. Routes with a lower metric value take priority over routes with a higher cost.	None

When finished, click **CREATE**.



## Routing Table

To view the current routing table, click **Routing Table** under **Routing > Unicast Route** in the function tree.

### Routing Table

↻

Destination	Netmask	Gateway	Interface	Metric
192.168.0.0	255.255.255.0	0.0.0.0	LAN	0

# NAT (AWK-1161C, AWK-1165C Only)

The AWK Series supports Network Address Translation (NAT) and Port Forwarding in Client-Router operation mode. This feature translates the outgoing communication from private IPs to external IPs (WAN IP).

## Network Address Translate

The **NAT** page lets you enable NAT functionality and manage NAT rules. Click **NAT** in the function tree.

**Network Address Translate**

Rule List

NAT Global Status \*  
Enabled

+

Search

Status	Name	Description	Pri.	Mode	Protocol	WAN IP : Port	LAN IP : Port
Enabled			32	N-to-1	--	--	--

Max 32

Items per page: 10 1 - 1 of 1


APPLY

Configure the following setting:

### **NAT Global Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the NAT function.	Enabled

## Add a New NAT Rule

To add a new NAT rule, click the **Add**  icon.

### Create NAT Rule

Rule Status \*  
Disabled ▼

Name  
 0 / 31

Description  
 0 / 127

Priority \*  
1

1 - 31

NAT Mode \*  
 ▼

CANCEL
APPLY

Configure the following settings:

### Rule Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the NAT rule.	Disabled

### Name

Setting	Description	Factory Default
0 to 31 characters	Enter a name for this rule.	None

### Description

Setting	Description	Factory Default
0 to 127 characters	Enter a description for this rule.	None

### Priority

Setting	Description	Factory Default
1 to 31	Specify the priority for this rule.	1

### NAT Mode

Setting	Description	Factory Default
1 to 1	Set the NAT mode to 1-to-1.	None
PAT	Set the NAT mode to PAT (Port Address Translation).	

### Mapping Type (1 to 1 Mode only)

Setting	Description	Factory Default
Single to Single	Set the mapping type to Single to Single.	Single to Single
Range to Range	Set the mapping type to Range to Range.	
Subnet to Subnet	Set the mapping type to Subnet to Subnet.	

### Mapping Type (PAT Mode only)

Setting	Description	Factory Default
Single Port	Set the mapping type to Single Port.	Single Port
Multiple Ports	Set the mapping type to Multiple Ports.	

**Protocol (PAT Mode only)**

Setting	Description	Factory Default
TCP/UDP	Specify the protocol.	TCP, UDP

**WAN**



Setting	Description	Factory Default
IP address	For 1-to-1 mode only. Specify the IP address for the WAN.	None
0 to 65535	For PAT mode only. Specify the TCP or UDP port number for the WAN.	None

**LAN**

Setting	Description	Factory Default
IP address	Specify the LAN IP address.	None
0 to 65535	For PAT mode only. Specify the LAN TCP or UDP port number.	None

Click **APPLY** to create the new NAT rule.

For **1 to 1 NAT Mode** and **PAT Mode**, refer to the following figure illustrations.



## Edit an Existing NAT Rule

To edit an existing NAT rule, click the **Edit**  icon next to the rule you want to edit. Refer to **Create a New NAT Rule** for more information about each setting.

<input type="checkbox"/>	Status	Name	Description	Pri.	Mode
<input type="checkbox"/>	Enabled			32	N-to-1

### Edit NAT Rule

Rule Status \*  
Enabled

Name  
 0 / 31

Description  
 0 / 127

Priority  
32  
.....  
1 - 32

NAT Mode  
N-to-1


When finished, click **APPLY**.


## View the NAT Rule Status

You can view the status of all NAT rules from the NAT rule list page.

<input type="checkbox"/>	Status	Name	Description	Pri.	Mode	Protocol	WAN IP : Port	LAN IP : Port
<input type="checkbox"/>	Enabled	Rule 1	Rule 1 for the field site	32	N-to-1	--	--	--

Max 32 Items per page: 10 1 - 1 of 1

You select what information you want to view by clicking **Select Visible Columns**  icon and checking the corresponding check boxes.



- Enable
- Name
- Description
- Pri.
- Mode
- Protocol
- WAN IP : Port
- LAN IP : Port


Only information for the selected items will be shown.

<input type="checkbox"/>	Status	Name	Description	Mode	WAN IP : Port	LAN IP : Port
<input type="checkbox"/>	Enabled	Rule 1	Rule 1 for the field site	N-to-1	--	--

Max 32 Items per page: 10 1 - 1 of 1


# Firewall

The **Firewall** section contains the **Layer 2 Policy** and **Layer 3 Policy** configuration pages.



## Layer 2 Policy

From the **Layer 2 Policy** screen, you can manage the L2 firewall policy and create, edit, and delete policy rules. Click **Layer 2 Policy** under **Firewall** in the function tree to access this screen.

A screenshot of the "Layer 2 Policy" configuration screen. At the top, there is a header "Layer 2 Policy". Below it, there are two dropdown menus: "Layer 2 Firewall Status" set to "Disabled" and "Default Action" set to "Drop". There is a plus sign icon for adding rules. Below that is a table header with columns: "Status", "Pri.", "Action", "Src. MAC Address", and "Dst. MAC Address". Below the table header, it says "Max 64". At the bottom, there is an "APPLY" button.

Configure the following settings:

### Layer 2 Firewall Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Layer 2 firewall function.	Disabled

### Default Action

Setting	Description	Factory Default
Accept	Accept all packets that do not match any policy rule.	Drop
Drop	Drop all packets that do not match any policy rule.	



## ATTENTION


Be careful when configuring the packet filtering function:


If the default action is set to **Drop** and **all rules are disabled, all packets will be denied.**

If the default action is set to **Accept** and **all rules are disabled, all packets will be allowed.**


When finished, click **APPLY** to save your changes.

## Add a New Layer 2 Firewall Rule

To add a new Layer 2 firewall rule, click the **Add**  icon.



Configure the following settings:



### Rule Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Layer 2 firewall rule.	Disabled

### Priority

Setting	Description	Factory Default
1 to 64	Specify the priority for this rule. A lower number represents a higher priority. Rules with a higher priority will be checked and enforced first.	1

### Default Action

Setting	Description	Factory Default
Accept	Packets that match the policy rule will be allowed.	Accept
Drop	Packets that match the policy rule will be denied.	



## ATTENTION

Be careful when configuring the packet filtering function:

If the default action is set to **Drop** and **all rules are disabled**, all packets will be allowed.



If the default action is set to **Accept** and **all rules are disabled**, all packets will be denied.

#### Source MAC Address

Setting	Description	Factory Default
MAC address	Enter the source MAC address.	Any

#### Destination MAC Address

Setting	Description	Factory Default
MAC address	Enter the destination MAC address.	Any

When finished, click **APPLY**.

## Layer 3 Policy

From the **Layer 3 Policy** screen, you can manage the L3 firewall policy and create, edit, and delete policy rules. Click **Layer 3 Policy** under **Firewall** in the function tree to access this screen.

### Layer 3 Policy

Layer 3 Firewall Status  
Disabled

Default Action  
Drop



<input type="checkbox"/>	Status	Pri.	Action	Protocol	Src. IP Address : Port	Dst. IP Address : Port
--------------------------	--------	------	--------	----------	------------------------	------------------------

Max 64

**APPLY**

Configure the following settings.

#### Layer 3 Firewall Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Layer 3 firewall function.	Disabled

#### Default Action

Setting	Description	Factory Default
Accept	Packets that match the policy rule will be allowed.	Drop
Drop	Packets that match the policy rule will be denied.	



### ATTENTION


Be careful when configuring the packet filtering function:


If the default action is set to **Drop** and **all rules are disabled**, all packets will be allowed.

If the default action is set to **Accept** and **all rules are disabled**, all packets will be denied.


When finished, click **APPLY**.

## Add a New Layer 3 Firewall Rule

To add a new Layer 3 firewall rule, click the **Add**  icon.



Configure the following settings:



### Rule Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the Layer 3 firewall rule.	Disabled

### Priority

Setting	Description	Factory Default
1 to 64	Specify the priority for this rule.	1

### Default Action

Setting	Description	Factory Default
Accept	Packets that match the policy rule will be allowed.	Accept
Drop	Packets that match the policy rule will be denied.	

### Protocol

Setting	Description	Factory Default
All	Filter all protocol traffic.	All
ICMP	Only filter for ICMP protocol traffic.	
TCP	Only filter for TCP protocol traffic.	
UDP	Only filter for UDP protocol traffic.	

The AWK's IP protocol filter is a policy-based filter that can allow or filter out IP-based packets with specified IP protocol and source/destination IP addresses.

The AWK provides 64 entities for setting IP protocol and source/destination IP addresses in your filtering policy. Four IP protocols are available: **All**, **ICMP**, **TCP**, and **UDP**. You must specify either the Source IP or the Destination IP. By combining IP addresses and netmasks, you can specify a single IP address or a range of IP addresses to accept or drop. For example, "IP address 192.168.1.1 and netmask 255.255.255.255" refers to the sole IP address 192.168.1.1. "IP address 192.168.1.1 and netmask 255.255.255.0" refers to the range of IP addresses from 192.168.1.1 to 192.168.255.

### Source

#### IP Address

Setting	Description	Factory Default
IP address	Specify the source IP address.	Any

#### Netmask

Setting	Description	Factory Default
Netmask	Select the subnet mask	32 (255.255.255.255)

#### Port Range

Setting	Description	Factory Default
0 to 65535	If the Protocol is set to TCP or UDP, specify the port range.	None

### Destination

#### IP Address

Setting	Description	Factory Default
IP address	Specify the destination IP address.	Any

#### Netmask

Setting	Description	Factory Default
Netmask	Specify the subnet mask.	32 (255.255.255.255)

#### Port Range

Setting	Description	Factory Default
0 to 65535	If the Protocol is set to TCP or UDP, specify the port range.	None


When finished, click **APPLY**.

## Certificate Management

The **Certificate Management** page provides a holistic presentation of all the configuration features that support certificate-based authentication. From this dashboard table, administrators can easily review and edit device or Server CA certificates without having to navigate to the individual feature's configuration page, simplifying and speeding up certificate management tasks.

For example, administrators can update the certificate and key of Syslog Server 1 through the **Certificate Management** page, instead of having to navigate to **Diagnostics > Event Logs and Notifications > Syslog > Authentication** to perform the same task.

# Basic Concept of SSL



## Device Certificate


The **Device Certificate** table shows the current certificate for the listed functions. The AWK Series supports different certificates for different functions to increase security and minimize the potential risk in the event a certificate is compromised.

Certificate Management						
Device Certificate						
Function	Issue To	Issue By	Start Date	Expiration Date	Serial Number	Search
Data Transferring	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:35:54 2022 GMT	Jun 9 11:35:54 2027 GMT	10AD0CC136A688DBFAE9F23FD5E7A170E5C637A	
HTTPS	moxa-awk-4252a	moxa-awk-4252a	Jun 14 15:11:30 2022 GMT	Jun 13 15:11:30 2027 GMT	68E874CE1A7DD76482FDD48BC2A92356C602CB73	
RSSI Report	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:36:20 2022 GMT	Jun 9 11:36:20 2027 GMT	17A4505C1B765433A2BE95A6021A820E418EAF31	
Syslog Server 1	moxa-awk-4252a	moxa-awk-4252a	Jun 14 15:15:23 2022 GMT	Jun 13 15:15:23 2027 GMT	260770B9701E5BA73694EE9FBD9EA48B0D5011AA	
Syslog Server 2	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:36:02 2022 GMT	Jun 9 11:36:02 2027 GMT	3470D83D8615E1259F693BA4E20AC62F07FF63E7	
Syslog Server 3	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:36:18 2022 GMT	Jun 9 11:36:18 2027 GMT	136CB52E4FE0CF16EE41222AA49F74CF2D6FC6FA	
Wi-Fi Client	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:36:23 2022 GMT	Jun 9 11:36:23 2027 GMT	18DD4729FAE2FB21F7A9CA72AC23D833F19B36DD	
Wi-Fi Sniffer and Wi-Fi Mirroring	moxa-awk-4252a	moxa-awk-4252a	Jun 10 11:36:31 2022 GMT	Jun 9 11:36:31 2027 GMT	02A8B18961592530FDEEC61C226CD81D14AD7BDE	

Table Field Name	Description
Function	The list of certificate-based authentication functions: Data Transferring HTTPS RSSI Report Syslog Server 1/2/3 Wi-Fi Client Wi-Fi Sniffer and Wi-Fi Mirroring

Table Field Name	Description
Issue To	The entity the certificate was issued to.
Issue By	The entity the certificate was issued by.
Start Date	The valid start date of the certificate.
Expiration Date	The expiration date of the certificate.
Serial Number	The unique serial number of the certificate.

By default, the certificates applied on the device are self-signed by the AWK device. It is recommended to update the self-signed certificate or upload a certificate issued by a trusted certificate authority (CA) for any functions that will be actively used.



## Server CA Certificate

From the **Server CA Certificate** screen, administrators can upload third-party trusted CA certificates which are used to verify the authenticity of received server certificates during the signature verification process of the listed applications.

### Server CA Certificate

Function	Issue To	Issue By	Start Date	Expiration Date	Serial Number
<input type="checkbox"/> Data Transferring	---	---	---	---	---
<input type="checkbox"/> Email Notification	---	---	---	---	---
<input type="checkbox"/> RSSI Report	---	---	---	---	---
<input type="checkbox"/> Syslog Server 1	---	---	---	---	---
<input type="checkbox"/> Syslog Server 2	---	---	---	---	---
<input type="checkbox"/> Syslog Server 3	---	---	---	---	---
<input type="checkbox"/> Wi-Fi Client	---	---	---	---	---

Max 7 1 - 7 of 7




## ATTENTION

The AWK Series device will automatically check and issue a warning message if the uploaded certificate has expired or was not issued by a trusted CA. Please note that the device will not automatically connect to public key infrastructure (PKI) to verify whether the uploaded certificate has been revoked or not. It is highly recommended to take additional measures to manually confirm the validity of the certificate (i.e. valid and not revoked) before uploading it to the device.


# Security

The **Security** section lets you configure **Device Security** settings.



## Device Security

This section describes how to configure the settings for **Login Policy**.



## Login Policy

On the **Login Policy** page, you can configure login messages and login security functions. Click **Login Policy** under **Security > Device Security** in the function tree to access this screen.

## Login Policy

Login Message  
 \_\_\_\_\_  
 0 / 500

Login Failure Message  
 Failed to login  
 \_\_\_\_\_  
 15 / 500

User Lockout Status \*  
 Enabled ▾

Login Failure Retry Threshold \*  
 5  
 1 - 10 time(s)

Lockout Period \*  
 5  
 1 - 10 min.

Session Lifetime \*  
 10  
 5 - 14400 min.

APPLY

Configure the following settings:

### ***Login Message***

Setting	Description	Factory Default
0 to 500 characters	Enter the message that will be displayed on the login screen when accessing the device.	None

### ***Login Failure Message***

Setting	Description	Factory Default
0 to 500 characters	Enter the message that will be displayed when users fail to log in.	Failed to login

### ***User Lockout Status***

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the lockout function when a user fails to log in.	Enabled

### ***Login Failure Retry Threshold***

Setting	Description	Factory Default
1 to 10	Specify the maximum number of times a user can attempt to log in again after a failed attempt.	5

### ***Lockout Period***

Setting	Description	Factory Default
1 to 10 (min.)	Specify the duration (in minutes) the user will be unable to log in for after exceeding the number of allowed retries.	5

### ***Session Lifetime***

Setting	Description	Factory Default
5 to 1440 (min.)	Specify how long a user can be inactive for before being automatically logged out and be required to log in again.	10

When finished, click **APPLY**.

## Trusted Access

In order to prevent DoS attacks, the Layer 2 and Layer 3 Trusted Access features allow authorized users to designate the MAC or IP addresses respectively that are allowed to access this device. When configured and enabled, the Trusted Access list will only allow the specified IP or MAC addresses access to the corresponding interfaces, databases, or services.

Trusted Access applies to the following interfaces, databases, and services:

- User interfaces: HTTP/HTTPS, SSH/Telnet, SNMP, New Moxa Command.
- Event logs and notifications: Syslog, Email notifications, SNMP Trap/Inform.
- Services: DHCP Server, Wi-Fi Sniffer, Mirroring with Remote Type.


The screenshot shows the 'Trusted Access' configuration page with the 'Layer 2 Trusted Access' tab selected. The status is set to 'Enabled'. A modal dialog titled 'Create L2 Trusted Access Entry' is open, showing a 'Status' dropdown set to 'Enabled' and a 'MAC Address' input field. The dialog has 'CANCEL' and 'APPLY' buttons at the bottom right.

The screenshot shows the 'Trusted Access' configuration page with the 'Layer 3 Trusted Access' tab selected. The status is set to 'Enabled'. A modal dialog titled 'Create L3 Trusted Access Entry' is open, showing a 'Status' dropdown set to 'Enabled', an 'IP Address' input field, and a 'Netmask' dropdown set to '32 (255.255.255.255)'. The dialog has 'CANCEL' and 'APPLY' buttons at the bottom right.

## Diagnostics


The **Diagnostics** section is used for monitoring and troubleshooting and includes the **System Status**, **Network Status**, **Event Logs and Notifications**, and **Tools** pages.





## Security Status

The Security Status screen consolidates the security status of all active interfaces of the device. This table serves as a review tool to ensure that the device's configuration meets the desired IEC-62443 Security Level (SL) profile. If any of the configuration risks do not meet your organization's security policy, check the description, and navigate to the corresponding configuration page to address the issue. If the identified risk cannot be directly mitigated through the AWK Series' configuration, such as an active unsecure protocol to support legacy devices, consider consulting a qualified security expert to implement additional measures to mitigate the risk.




Field	Description
Status	The representative icons indicate if there are any risks that require mitigating action, and the corresponding severity of the risk. Risks that have been addressed will be marked with a checkmark.
Risk Level	The device categorizes risks into three tiers: <b>Low:</b> Risks vulnerable to exploitation per circumstances defined in SL3 and above. <b>Medium:</b> Risks vulnerable to exploitation per circumstances defined in SL2. <b>High:</b> Risks vulnerable to exploitation per circumstances defined in SL1.
Risk Description	Additional details describing the risk to provide administrators with context for taking the appropriate hardening action.

# System Status


## Utilization

The **Utilization** screens features widgets and charts showing the real-time resource usage of the AWK. Click **Utilization** under **Diagnostics > System Status** in the function tree to access this screen.




## CPU Usage

This widget shows the current CPU usage.



## CPU Usage History


The graph shows the CPU usage history.






## Memory Usage

This widget shows the current memory usage.




## Memory Usage History

This graph shows the memory usage history.




# Network Status

The **Network Status** section contains the **Network Statistics**, **LLDP**, **Bridge Table**, and **ARP Table** pages.



## Network Statistics

The **Network Statistics** page shows real-time data for all interfaces. Click **Network Statistics** under **Diagnostics > Network Status** in the function tree to access this page.

The screenshot shows the "Network Statistics" page header with a refresh icon and timestamp "2022-10-11 13:14:47". Below the header is a table with 11 columns: Interface, Tx. Total Bytes, Tx. Total Pkt., Tx. Unicast Pkt., Tx. Multicast Pkt., Tx. Broadcast Pkt., Rx. Total Bytes, Rx. Total Pkt., Rx. Unicast Pkt., Rx. Multicast Pkt., and Rx. Broadcast Pkt. The table lists four interfaces: LAN 1, LAN 2, SSID-5 GHz: Moxa\_Guest, and SSID-5 GHz: Moxa\_OT. LAN 1 shows the highest activity with 7441881 Tx. Total Bytes and 3891 Rx. Total Pkt. LAN 2 shows 2634741 Tx. Total Bytes and 983 Rx. Total Pkt. The wireless interfaces show zero activity. A search bar and navigation icons are visible above the table. The footer of the table area indicates "1 - 4 of 4".

Interface	Tx. Total Bytes	Tx. Total Pkt.	Tx. Unicast Pkt.	Tx. Multicast Pkt.	Tx. Broadcast Pkt.	Rx. Total Bytes	Rx. Total Pkt.	Rx. Unicast Pkt.	Rx. Multicast Pkt.	Rx. Broadcast Pkt.
LAN 1	7441881	3359	7674	29	23	579367	3891	3675	164	54
LAN 2	2634741	725	2363	3	1	125430	983	836	118	29
SSID-5 GHz: Moxa_Guest	0	0	0	0	0	0	0	0	0	0
SSID-5 GHz: Moxa_OT	0	0	0	0	0	0	0	0	0	0

## LLDP

LLDP is an OSI Layer 2 protocol defined by IEEE 802.11AB. LLDP standardizes the self-identification advertisement method, and allows each networking device, such as a Moxa managed switch or access point, to periodically send its system and configuration information to its neighbors. Because of this, all LLDP devices are kept informed of each other's status and configurations. With SNMP, this information can be used to generate network visualization.

From the web interface, you can enable or disable LLDP, and set the LLDP transmit interval. In addition, you can view the neighbor-list, which is reported by its network neighbors.

## LLDP Settings

Click the **Settings** tab to enable or disable LLDP and set the transmission interval.

**LLDP**

Settings Status

LLDP Status \*  
Enabled

Transmission Interval  
30  
5 - 4095 sec.

APPLY

Configure the following settings:

### LLDP Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable LLDP.	Enabled

### Transmission Interval

Setting	Description	Factory Default
5 to 4095 (sec.)	Specify the transmission interval at which LLDP messages are sent.	30



## NOTE

The LLDP protocol transmits data in clear text and discloses the device model name.

When finished, click **APPLY**.

## LLDP Status

Click the **Status** tab to view the LLDP status.

**LLDP**

Settings Status

Search

Local Port	Nbr. System Name	Nbr. System Description	Nbr. System Capability	Nbr. Chassis ID	Nbr. Management Address	Nbr. Port ID	Nbr. Port Description
LAN 2	--	--	--	9c:eb:e8:b1:2c:27	--	9c:eb:e8:b1:2c:27	--

Items per page: 20 1 - 1 of 1 |< < > >|

# Bridge Table

The **Bridge Table** page provides more detailed bridging information. Click **Bridge Table** under **Diagnostics > Network Status** in the function tree to access this screen.


**Bridge Table**

🔄 📄

MAC Address	Interface	Aging Timer (sec.)
00:00:02:00:00:00	SSID: .M-Guest	44.55
00:02:E7:06:EE:27	SSID: .M-Guest	11.45
00:02:E7:09:7B:4A	SSID: .M-Guest	18.78
00:90:E8:A7:79:8E	Local	0.00
9C:EB:E8:B1:2C:27	LAN 2	0.04

## ARP Table

The **ARP Table** page shows all ARP entries. Click **ARP Table** under **Diagnostics > Network Status** in the function tree to access this screen.




IP Address	MAC Address
192.168.0.40	02:11:32:2B:C2:05
192.168.0.10	D8:BB:C1:08:6B:BD
192.168.0.1	00:11:32:88:1D:17

Max 1024

## Event Logs and Notifications

The **Event Logs and Notifications** section is used to configure event and notification settings and includes the **Event Log**, **Notifications**, **Syslog**, **SNMP Trap/Inform**, **Email Settings**, and **Relay Alarm Cut-off** pages.






### Event Log

From the **Event Log** page, you can view the current log list, configure the log oversize action, and back up the event log. Click **Event Log** under **Diagnostics > Event Logs and Notifications** in the function menu to access this page.









## Log List

Click the **Log List** tab to view a list of all logged events.

Event Log						
Log List	Registered Logs	Oversize Action	Backup			
  						<input type="text" value="Search"/>
Index	Bootup Number	Severity	Timestamp	Uptime	Group	Message
1	2	Notice	2022-10-11 13:20:07.397128	0d00h17m52s	System	Configuration saved successfully. (User: admin, IP: 192.168.127.2, Interface: HTTPS)
2	2	Notice	2022-10-11 13:20:07.204867	0d00h17m51s	System	Device configuration was changed. (User: admin, IP: 192.168.127.2, Interface: HTTPS)
3	2	Notice	2022-10-11 13:18:50.952219	0d00h16m35s	Wi-Fi	[M-Guest] Installed key successfully for the AP [7c:57:3c:2e:ba:12].
4	2	Notice	2022-10-11 13:18:50.951461	0d00h16m35s	Wi-Fi	[M-Guest] Successfully connected to AP [7c:57:3c:2e:ba:12].
5	2	Notice	2022-10-11 13:18:50.914628	0d00h16m35s	Wi-Fi	[M-Guest] Successfully associated with AP [7c:57:3c:2e:ba:12].

## Registered Logs

Click the **Registered Logs** tab to view and edit event log groups.

Event Log			
Log List	Registered Logs	Oversize Action	Backup
Group Name	Status	Action	
 Wi-Fi	Enabled	Local, Syslog	
 Network	Enabled	Local, Syslog	
 System	Enabled	Local, Syslog	
 Account	Enabled	Local, Syslog	
 Configuration	Enabled	Local, Syslog	
 Power	Enabled	Local, Syslog	

To edit an event log group, click the **Edit**  icon next to the group you want to edit.

### Edit Event Log Registration

Group Name  
Wi-Fi

Log Registration Status \*  
Enabled

Action \*  
Local, Syslog

CANCEL APPLY

Configure the following settings:

#### Log Registration Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the log group. If disabled, events associated with this group will not be logged.	Enabled

#### Action

Setting	Description	Factory Default
Local	Save the event logs locally.	Local, Syslog
Syslog	Send the event logs to a Syslog server.	

When finished, click **APPLY**.

## Oversize Action

From the **Oversize Action** page, you can configure what happens when the log capacity has been reached. Click the **Oversize Action** tab to access this screen.

### Event Log

Log List   Registered Logs   **Oversize Action**   Backup

Oversize Action  
Overwrite the oldest event log

Capacity Warning Status \*  
Disabled i

APPLY

---

#### Automatically Back Up Event Logs to ABC-02

Auto Backup Status \*  
Disabled

APPLY

Configure the following settings:

#### **Oversize-Action**

Setting	Description	Factory Default
Overwrite the oldest event log	Overwrite the oldest event log.	Overwrite the oldest event log
Stop recording event log	Stop recording new event logs.	

#### **Capacity Warning**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable event log capacity warnings.	Disabled

When finished, click **APPLY**.

#### **Auto Backup Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable automatic event log backups to an ABC-02.	Disabled

When finished, click **APPLY**.

## **Backup**

Click **Backup** tab to select the storage location.

#### **Storage Location**

Setting	Description	Factory Default
Local	Back up the event log to the local storage on the AWK device.	None
TFTP	Back up the event log via TFTP.	
SFTP	Back up the event log via SFTP.	
ABC-02	Back up the event log to an ABC-02 USB tool.	

#### **Server IP Address (for TFTP only)**

Setting	Description	Factory Default
IP address	Enter the IP address of the TFTP server.	None

#### **File Name (for TFTP only)**

Setting	Description	Factory Default
Input the backup file name	Enter the file name of the event log backup.	None

#### **Server IP Address (for SFTP only)**

Setting	Description	Factory Default
IP address	Enter the IP address of the SFTP server.	None

#### **Pathname (for SFTP only)**

Setting	Description	Factory Default
Pathname	Specify the file path on the SFTP server for storing the event log backup.	None

**Account (for SFTP only)**

Setting	Description	Factory Default
Account name	Enter the SFTP server account name.	None

**Password (for SFTP only)**

Setting	Description	Factory Default
Password	Enter the SFTP server account password.	None







**Select Folder (for ABC-02 only)**

Setting	Description	Factory Default
Folder	Select the folder on the ABC-02 to store the event log backup in.	None

When finished, click **BACKUP**.

## Notifications

You can configure the notification settings for individual event types. Click **Notifications** under **Diagnostics > Event Logs and Notifications** in the function tree to access this screen.

Notifications					
Group	Event Name	Status	Severity	Notification Method	
 System	Cold start	Enabled	Notice	Trap, Email	
 System	Warm start	Enabled	Notice	Trap, Email	
 System	Configuration changed	Enabled	Notice	Trap, Email	
 System	Reaching log capacity	Enabled	Alert	Trap, Email	
 Power	Power 1 turned on	Enabled	Warning	Trap, Email	
 Power	Power 1 turned off	Enabled	Warning	Trap, Email	

To edit the notification settings, click the **Edit**  icon next to the event you want to edit.

### Edit Event Notification

Event Name  
Cold start

Event Notification Status \*  
Enabled

Notification Method  
Trap, Email

CANCEL APPLY

Configure the following settings:

#### Event Notification Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable notifications for this event.	Enabled

#### Notification Method

Setting	Description	Factory Default
Trap	Send notifications through SNMP Trap.	Trap/Email
Email	Send notifications through email.	
Relay	Use a relay for sending notifications. This option is only available for specific event groups.	

When finished, click **APPLY**.

## Syslog

You can set up one or more Syslog servers to store event logs. Click **Syslog** under **Diagnostics > Event Logs and Notifications** in the function tree to access this screen.

Configure the following settings:

#### Syslog Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable logging events to a syslog server.	Disabled

#### Event Reporting Severity

Setting	Description	Factory Default
Emerg.	Specify the syslog severity as Emergency.	Info.
Alert	Specify the syslog severity as Alert.	
Crit.	Specify the syslog severity as Critical.	
Error	Specify the syslog severity as Error.	
Warning	Specify the syslog severity as Warning	
Notice	Specify the syslog severity as Notice.	
Info.	Specify the syslog severity as Information.	

#### Syslog Server 1 Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the first syslog server.	Disabled

### Syslog Server 2 Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the second syslog server.	Disabled

### Syslog Server 3 Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the third syslog server.	Disabled


When finished, click **APPLY**.

## SNMP Trap/Inform

The **SNMP Trap/Inform** section is used for setting up SNMP Traps and Inform triggers for events. Click **SNM Trap/Inform** under **Diagnostics > Event Logs and Notifications** in the function tree to access this page.

### SNMP Trap/Inform

General SNMP Trap/Inform Account



<input type="checkbox"/>	Recipient IP/Name	Mode	Trap Community

Max 2

#### SNMP Inform Settings


Inform Retry \*

1 - 99

Inform Timeout \*

1 - 300 sec.

## General Settings

From the **General** tab, you can manage SNMP Trap/Inform recipients. Click the **General** tab to access this screen. Click the **Add**  icon to create a new entry.

### Create SNMP Trap/Inform Recipient

Recipient IP/Name \*  
 0 / 60

Mode\*  
 Disabled ▼

CANCEL
APPLY

Configure the following settings:

#### **Recipient IP/Name**

Setting	Description	Factory Default
0 to 60 characters or IP address	Enter the name or IP of the recipient.	None

#### **Mode**

Setting	Description	Factory Default
Disabled	Disable the SNMP Trap/Inform function.	Disabled
Trap V1	Set the trap version to Trap V1.	
Trap V2c	Set the trap version to Trap v2c.	
Inform V2c	Set the inform version to Inform V2c.	
Trap V3	Set the trap version to Trap V3.	
Inform V3	Set the inform version to Inform V3.	

When finished, click **APPLY**.

## SNMP Inform Settings

From the SNMP Inform Settings screen, users can make sure SNMP Inform notice packets are sent and received reliably. Users can specify the number of times the system will try to send an inform notice until receiving confirmation from the SNMP Server. Configure the following settings.

#### **Inform Retry**


Setting	Description	Factory Default
1 to 99	Specify the maximum number of Inform retries.	3


#### **Timeout**

Setting	Description	Factory Default
1 to 300	Specify the Inform timeout value.	10


When finished, click **APPLY**.

## SNMP Trap/Inform Account Settings

From the **SNMP Trap/Inform Account** tab, you can manage SNMP Trap/Inform accounts. Click the **SNMP Trap/Inform Account** tab to access this screen. Click the **Add**  icon to create a new entry.



Configure the following settings:



### **Username**

Setting	Description	Factory Default
At least 4 characters, (max. 32 characters)	Enter a username for the account.	None

### **Authentication type**

Setting	Description	Factory Default
None	Do not use any authentication mechanism.	None
MD5	Use MD5 as the authentication type.	
SHA	Use SHA as the authentication type.	

### **Authentication Password (when the Authentication type is set to MD5 or SHA)**

Setting	Description	Factory Default
8 to 64 characters	Enter the authentication password.	None

### **Encryption Method (when the Authentication type is set to MD5 or SHA)**

Setting	Description	Factory Default
None	Do not use any encryption.	None
DES	DES is the encryption method.	
AES	AES is the encryption method.	

### **Encryption Key (when DES and AES is selected)**

Setting	Description	Factory Default
8 to 64 characters	Enter the encryption key.	None

When finished, click **APPLY**.



## Email Settings

The **Email Settings** page is used to configure email settings for notifications, including the email server, sender, and recipients. Click **Email Settings** under **Diagnostics > Event Logs and Notifications** in the function tree to access this screen.

### Email Settings

Email Server \*

SMTP: TCP Port  
  
0 - 65535

Authentication Status \*  
Disabled ▼ Username  Password \*

Security \*  
None ▼

Sender Email Address

1st Email Recipient     2nd Email Recipient     3rd Email Recipient

4th Email Recipient     5th Email Recipient

APPLY

Configure the following settings.

### **Email Server**

Setting	Description	Factory Default
IP address or URL	The IP address or URL of the email server.	None

### **SMTP: TCP Port**

Setting	Description	Factory Default
0 to 65535	The TCP port number of the email server.	25

### **Authentication Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable authentication for the email server.	Disabled

### **Username**

Setting	Description	Factory Default
Max. 60 characters	Enter the email user account.	None

### **Password**

Setting	Description	Factory Default
Max. of 60 characters	Enter the email user password	None

### Security

Setting	Description	Factory Default
None	Do not use any security method.	None
STARTTLS	Use STARTTLS as the security method.	
SSL/TLS	Use SSL/TLS as the security method.	

### Sender Email Address

Setting	Description	Factory Default
Max. 60 characters	Enter the sender's email address.	None


### 1st to 5th Email Addresses

Setting	Description	Factory Default
Max. 60 characters	Enter the recipient's email address. You can set up to five recipient email addresses to receive alert emails from the AWK device.	None

When finished, click **APPLY**.


## Tools

The Tools section contains several diagnostics and troubleshooting tools for the AWK, including **Wi-Fi Tools**, **System Data Collection**, **Diagnostic Support**, and **Ping**.



### Wi-Fi Tools

Under **Wi-Fi Tools** are the **Channel Scan**, **Wi-Fi Mirroring**, and **RSSI Reporting** functions.



### Channel Scan

The Channel Scan function is used to analyze the selected RF band for available channels. Click **Channel Scan** under **Diagnostics > Tools > Wi-Fi Tools** in the function tree to access this screen.

## Channel Scan

RF Band \* ▼

---

ANALYZE

Configure the following setting:

**RF Band**

Setting	Description	Factory Default
5 GHz	Scan the 5 GHz RF band.	None
2.4 GHz	Scan the 2.4 GHz RF band.	
5 GHz & 2.4 GHz	Scan both 5 GHz and 2.4 GHz RF bands.	

When finished, click **ANALYZE**.

When prompted, click **ANALYZE** again.

### Analyze Channels

Wi-Fi performance will be affected during the channel analysis. Are you sure you want to continue?

**CANCEL** **ANALYZE**


The result of the scan will be shown in the table at the bottom of the page. The Load(%) metric indicates the time the channel was used (in percentage) during the scan. The scan duration is approximately 330 ms for each channel.

### Channel Analyze Result: 5GHz

Channel	Number of APs	Load(%)	Noise Floor (dBm)
36 (5180 MHz)	3	2	-106
40 (5200 MHz)	0	1	-106
44 (5220 MHz)	0	1	-105
48 (5240 MHz)	0	1	-106
52 (5260 MHz)	0	1	-106
56 (5280 MHz)	0	0	-106
60 (5300 MHz)	0	0	-107
64 (5320 MHz)	0	0	-107
100 (5500 MHz)	0	1	-108

## Wi-Fi Mirroring

Wi-Fi Mirroring lets you copy the traffic of wireless traffic for analysis and troubleshooting purposes. Click **Wi-Fi Mirroring** under **Diagnostics > Tools > Wi-Fi Tools** in the function tree to access this screen.



Configure the following settings.

### **Mirroring Type**

Setting	Description	Factory Default
Local	Select Local to mirror traffic to the local storage on the device.	None
Remote	Select Remote to have the AWK act as a server to be used with capturing tool such as Wireshark to capture the mirror traffic.	

### **Mirroring Period (Local Type only)**

Setting	Description	Factory Default
1 to 60 (min.)	Specify how long the device will mirror wireless traffic.	None

When finished, click **START** to start mirroring, and **STOP** to stop mirroring.

The result of the mirroring will be shown below. If you selected Local as the mirroring type, click **DOWNLOAD** to download the result to your local machine.

## RSSI Reporting

RSSI Reporting sends out the AP's SNR or detected Signal Strength over Syslog to a designated recipient host for monitoring. This data is used to analyze if the configured Turbo Roaming Threshold and Roaming Difference values are suitable for the current network environment. Click **RSSI Reporting** under **Diagnostics > Tools > Wi-Fi Tools** in the function tree to access this screen.

## RSSI Reporting

General

Authentication

Status \*  
 Disabled ▼

Recipient  
 \_\_\_\_\_

TCP/UDP Port  
 514 i  
 0 - 65535

Reporting Interval \*  
 50  
 50 - 500 ms.

Security \*  
 None ▼

APPLY

### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable RSSI Reporting.	Disabled

### Recipient

Setting	Description	Factory Default
Host IP/Domain name	Specify the Syslog server host IP or domain name that will receive the RSSI report data.	Empty

### TCP/UDP Port

Setting	Description	Factory Default
0 to 65535	Specify the designated Syslog server communication port to receive the RSSI report data on.	None

### Reporting Interval

Setting	Description	Factory Default
50 to 500 ms	Specify the interval (in ms) at which RSSI report data is generated and sent to the Syslog server.	None

### Security

Setting	Description	Factory Default
None/TLS	Specify whether the generated RSSI report data needs to be TLS encrypted or not.	None

When finished, click **APPLY**.

## System Data Collection

The **System Data Collection** section contains the **One Key Information** and **Data Collection** functions.

### Download One Key Information

Using the **One Key Info** function, all running configuration files, event logs, and CLI status will be saved as a compressed ZIP file and stored on the selected medium. Click the **One Key Info**. Tab to access this screen.

## System Data Collection

One Key Info.
Data Collection

File Password \*

1 - 64

Storage Location \* ▼

DOWNLOAD

Configure the following settings:

**File Password**

Setting	Description	Factory Default
1 to 64 characters	Enter the password for the file. This password will be required to open the compressed file.	None

**Storage Location**

Setting	Description	Factory Default
Local	The file will be downloaded to the local storage on the AWK.	None
TFTP	The file will be downloaded to a TFTP server.	
SFTP	The file will be downloaded to an SFTP server.	
ABC-02	The file will be downloaded to the connected ABC-02 USB.	

**Server IP Address (for TFTP only)**

Setting	Description	Factory Default
IP address	Enter the IP address of the TFTP server.	None

**Server IP Address (for SFTP only)**

Setting	Description	Factory Default
IP address	Enter the IP address of the SFTP server.	None

**Server Account (for SFTP only)**

Setting	Description	Factory Default
Account name	Enter the account name of the SFTP server.	None

**Server Password (for SFTP only)**

Setting	Description	Factory Default
Account password	Enter the account password of the SFTP server.	None

When finished, click **DOWNLOAD** to download the file.

## Data Collection

The **Data Collection** function is used to gather selected system information at specific intervals. Click the **Data Collection** tab to access this screen.

### System Data Collection

One Key Info.
Data Collection

Interval \*

 sec.

Stop Date \* Stop Time

Storage Location \* ▼

Select the information to collect\*

- Wi-Fi Statistic
- Wi-Fi Connection
- Wi-Fi Tx/Rx
- Network
- Service
- System

START
STOP

Configure the following settings:

### **Interval**

Setting	Description	Factory Default
1 to 30 (sec.)	Specify the interval at which the AWK will collect information.	None

### **Stop Date**

Setting	Description	Factory Default
Date	Specify the date the device will stop collecting information.	None

### **Stop Time**

Setting	Description	Factory Default
Time	Specify the time the device will stop collecting information.	01:00 AM

### **Storage Location**

Setting	Description	Factory Default
Local	The file will be downloaded to the local storage on the AWK.	None
TFTP	The file will be downloaded to a TFTP server.	
SFTP	The file will be downloaded to an SFTP server.	
ABC-02	The file will be downloaded to the connected ABC-02 USB.	

### **Server IP Address (for TFTP only)**

Setting	Description	Factory Default
IP address	Enter the IP address of the TFTP server.	None



### Server IP Address (for SFTP only)

Setting	Description	Factory Default
IP address	Enter the IP address of the SFTP server.	None

### Server Account (for SFTP only)

Setting	Description	Factory Default
Account name	Enter the account name of the SFTP server.	None

### Server Password (for SFTP only)

Setting	Description	Factory Default
Account password	Enter the account password of the SFTP server.	None

### Select the information to collect

Setting	Description	Factory Default
Wi-Fi Statistic	Select the types of information you want to collect.	None
Wi-Fi Connection		
Wi-Fi Tx/Rx		
Network		
Service		
System		

When finished, click **START** to begin collecting information, and **STOP** to end.

## Diagnostic Support

This feature allows an authorized user to generate an engineering account for Moxa support staff to access and troubleshoot the AWK Series. Click **Diagnostic Support** under **Diagnostics > Tools** in the function tree to access this screen.

**Diagnostic Support**

**Generate Profile**

Duration  
10  
1 - 180 day(s)

**GENERATE**

**Generated Account Status**

Status  
---

Remaining Duration  
---

**DEACTIVATE**

### Duration

Setting	Description	Factory Default
1 to 180 (days)	Specify how long the diagnostics account will be active for.	None

You can check the account status at any time in the bottom section of the screen. Click **DEACTIVATE** to immediately terminate a generated diagnostics account.



### NOTE

Only provide generated diagnostics account credentials to authorized Moxa support personnel.

## Ping

The **Ping** function is used to check the connection to a remote host. Click **Ping** under **Diagnostics > Tools** in the function tree to access this screen.

The screenshot shows the 'Ping' configuration interface. It includes a title bar, a 'Target \*' field, an 'IPv4 Address/Host' field, a 'Ping Interval \*' field set to '1' (range 1-30 sec.), a 'Stop Method \*' dropdown set to 'Rounds', and a 'Rounds \*' field set to '3' (range 3-86400). There are 'PING' and 'STOP' buttons at the bottom.

Configure the following settings:

### Target

Setting	Description	Factory Default
IP address/hostname	Enter the IP address or hostname you want to ping.	None

### Ping Interval

Setting	Description	Factory Default
1 to 30 (sec.)	Specify the interval at which the AWK will ping the host.	1

### Stop Method

Setting	Description	Factory Default
Rounds	Specify Rounds as the stop method.	Rounds
Timestamps	Specify Timestamps as the stop method.	

### Rounds (for Rounds Method only)

Setting	Description	Factory Default
3 to 86400	Specify the round value.	3

### End Date (for Timestamps Method only)

Setting	Description	Factory Default
Date	Specify the date when to stop pinging the IP address or hostname.	None

### End Time (for Timestamps Method only)

Setting	Description	Factory Default
Time	Specify the time to stop pinging the IP address or hostname.	01:00 AM

When finished, click **PING** to begin pinging, or **STOP** to send.

## Setup Wizard

The **Setup Wizard** allows users to perform basic device configurations to get the AWK running quickly.

Click **Setup Wizard** in the function tree to start the Wizard, then follow the on-screen instructions. There are three configuration tabs: **Wi-Fi Basic**, **Wi-Fi Security**, and **System**. While the Wizard will start from the **Wi-Fi Basic** section by default, you can go to any other tab at any time.

# Wi-Fi Basic

Configure the following settings:

**1** Wi-Fi Basic

Operation Mode \*  
AP

Environment \*  
Indoor

**SSID: 5 GHz**

SSID Status \* Enabled      SSID \* Moxa\_OT  
7 / 32

Channel \* 36 (5180 MHz)      Bonded Channel(s) 40, 44, 48

**SSID: 2.4 GHz**

SSID Status \* Enabled      SSID \* Moxa\_Guest  
10 / 32

Channel \* 3 (2422 MHz)      Bonded Channel(s) 7

**NEXT**

## Operation Mode

Setting	Description	Factory Default
Disabled	Disable the operation mode.	Disabled
AP	Specify the operation mode as AP. Refer to <b>AP Mode Settings</b> (AWK-1161A, AWK-1165A only).	
Master	Specify the operation mode as Master. Refer to <b>Master Mode Settings</b> (AWK-1161A, AWK-1165A only).	
Client	Specify the operation mode as Client. Refer to <b>Client Mode Settings</b> (AWK-1161C, AWK-1165C only).	
Client-Router	Specify the operation mode as Client-Router. Refer to <b>Client-Router Mode Settings</b> (AWK-1161C, AWK-1165C only).	
Slave	Specify the operation mode as Slave. Refer to <b>Slave Mode Settings</b> (AWK-1161C, AWK-1165C only).	

## Environment

Setting	Description	Factory Default
Indoor	Set the application environment to indoor. Available channels vary depending on the selection.	Indoor
Outdoor	Set the application environment to outdoor. Available channels vary depending on the selection.	

## SSID: 2.4 GHz

### SSID Status

Setting	Description	Factory Default
Enabled/Disable	Enable or disable the SSID.	Disabled

**SSID**

Setting	Description	Factory Default
1 to 32 characters	Enter a name for the SSID.	None

**Channel (available in AP and Master modes only)**

Setting	Description	Factory Default
1 (2412 MHz) to 11 (2462 MHz)	Select the channel from the drop-down list. Each channel supports different frequencies.	6 (2437 MHz)

**Bonded Channel (available in AP and Master modes only)**

Setting	Description	Factory Default
10 (read only)	The bonded channel used by the AP will be shown here if channel width is set to 20/40 MHz.	None

**SSID: 5 GHZ****SSID Status**

Setting	Description	Factory Default
Enabled/Disable	Enable or disable the SSID.	Disabled

**SSID**

Setting	Description	Factory Default
1 to 32 characters	Enter a name for the SSID.	None

**RF Band (for Client, Client-Router, and Slave modes only)**

Setting	Description	Factory Default
5 GHz	Select 5 GHz as the RF band.	5 GHz
2.4 GHz	Select 2.4 GHz as the RF band.	
5 GHz & 2.4 GHz	Select both 5 GHz and 2.4 GHz as the RF bands.	

**5 GHz Channel Plan (for Client, Client-Router, and Slave modes only)**

Setting	Description	Factory Default
Channel	Select the channel for the 5 GHz band.	Any

**Channel (for AP and Master modes only)**

Setting	Description	Factory Default
36 (5180 MHz) to 165 (5825 MHz)	Select the channel from the drop-down list. Each channel supports different frequencies.	36 (5180 MHz)

**Bonded Channel (for AP and Master modes only)**

Setting	Description	Factory Default
40/44/48 (read only)	The bonded channel used by the AP will be shown here if channel width is set to 36 (5180 GHz).	None

When finished, click **NEXT**.

# Wi-Fi Security

## AP/Master Mode

**5 GHz**

SSID  
Moxa\_OT


Security \*  
WPA2

Protected Management Frame \*  
Disabled

WPA Mode \*  
Personal

Encryption \*  
AES

EAPOL Version \*  
1

Passphrase \*  
..... 

At least 8 characters 10 / 64

**2.4 GHz**

The SSID does not have any security enabled. We recommend disabling it.

SSID  
Moxa\_Guest

Security \*  
Open

**NEXT** **BACK**

## Client/Client-Router/Slave Mode

SSID  
.M-Guest


Security \*  
WPA2

Protected Management Frame \*  
Disabled

WPA Mode \*  
Personal

Encryption \*  
AES

EAPOL Version \*  
1

Passphrase  
..... 

At least 8 characters 8 / 64

**NEXT** **BACK**

### SSID

Setting	Description	Factory Default
SSID (read only)	Shows the name for the SSID.	None

## Security

Setting	Description	Factory Default
Open	Disable security on the SSID. This is not recommended.	Open
WPA	Use WPA authentication.	
WPA2	Use WPA2 authentication. This mode supports IEEE 802.11i with TKIP/AES + 802.1X encryption.	
WPA3	Use WPA3 authentication. This mode supports SAE (Simultaneous Authentication of Equals) to avoid network attacks, such as KRACK.	
WPA/WPA2 Mixed	Use WPA/WPA2 Mixed authentication. This allows both WPA and WPA2 clients to connect to the AWK.	
WPA2/WPA3 Mixed	Use WPA/WPA3 Mixed authentication. This allows both WPA2 and WPA3 clients to connect to the AWK.	

When using any security mode except **Open**, configure the following settings:

### Protected Management Frame

Setting	Description	Factory Default
Disabled	Disable the protected management frame. This option is not available when using WAP3.	Disabled
802.11w	Use 802.11w protocol as the protected management frame.	

### WPA type

Setting	Description	Factory Default
Personal	Use WPA, WPA2, and WPA3 with a Pre-shared Key (PSK).	Personal
Enterprise	Use WPA, WPA2, and WPA3 with EAP security.	

### Primary/Secondary RADIUS Server IP (for Enterprise mode only)

Setting	Description	Factory Default
IP address	Specify the RADIUS authentication server for EAP.	None

### Primary/Secondary RADIUS Port (for Enterprise mode only)

Setting	Description	Factory Default
0 to 65535	Specify RADIUS server port number.	1812

### Primary/ Secondary RADIUS Shared Key (for Enterprise mode only)

Setting	Description	Factory Default
0 to 128 characters	Enter the secret key shared for communication between AP and the RADIUS server. The key cannot contain the following special characters: ` ' "   ; & \$	None

### Encryption

Setting	Description	Factory Default
AES	Use Advance Encryption System (AES) encryption.	TKIP/AES Mixed
TKIP/AES Mixed*	Use TKIP/AES Mixed encryption. This option provides a TKIP broadcast key and TKIP+AES unicast key to support legacy AP clients. This option is rarely used and is not available when using WAP3.	

\*This option is available for legacy mode in AP/Master only and does not support AES-enabled clients.

### EAPOL Version

Setting	Description	Factory Default
1	Use EAPOL Version 1 as the security authentication method.	1
2	Use EAPOL Version 2 as the security authentication method.	

### Passphrase (for Personal mode only)

Setting	Description	Factory Default
8 to 63 characters	Enter the passphrase. This is the master key to generate keys for encryption and decryption. The passphrase cannot contain the following special characters: ` ' "   ; & \$ Check <b>Show Password</b> to display the password in clear text.	None

### EAP Protocol (for Enterprise mode only)

Setting	Description	Factory Default
TLS	Use EAP-TLS to validate the connection. This option allows the user to upload a TLS certificate to perform the identity check.	TLS
TTLS	Use TTLS to validate the connection. This option requires users to also specify the Anonymous Name, Username, and Password.	
PEAP	Use PEAP to validate the connection. This option requires users to also specify the Anonymous Name, Username, and Password.	

When finished, click **NEXT**.

## System

Device Name \*  
moxa-awk-3252a  
a-z, 0-9, and dash only 14 / 256

**Time**

Clock Source \*  
Sync From Browser ▼

Time Zone \*  
UTC+00:00 ▼

Daylight Saving Status \*  
Disabled ▼

**IP Configuration**

IP Mode \*  
Static ▼

IP Address \* 192.168.0.222 Subnet Mask \* 24 (255.255.255.0) ▼ Default Gateway \_\_\_\_\_

DNS Server 1 \_\_\_\_\_ DNS Server 2 \_\_\_\_\_

**APPLY** **BACK**

## Device Name

Setting	Description	Factory Default
1 to 255 characters	<p>Enter a name for the device. This is useful for differentiating between the roles or applications of different units. Note that the device name cannot be empty and must comply with the following naming rules:</p> <ul style="list-style-type: none"><li>• Only supports letters (a-z), numbers (0-9), and special character dash (-)</li><li>• Cannot contain any spaces</li><li>• Cannot start with dash (-)</li><li>• Cannot end with dash (-)</li><li>• When used in a PROFINET environment, cannot start with the prefix "port-x" where "x" equals 0 to 9. There is no validity check to identify incorrect name formats.</li></ul>	Moxa-awk-1161a

## Time

### Clock Source

Setting	Description	Factory Default
Sync From Browser	Synchronize the system clock with the browser's clock.	Sync From Browser
NTP	Set the clock source to NTP. This will sync the system clock with an external NTP server.	

### Time Server 1 (for Clock Source is NTP)

Setting	Description	Factory Default
NTP time server	Specify the IP or domain address of the primary NTP server to use (e.g., 192.168.1.1, time.stdtime.gov.tw, or time.nist.gov).	None

### Time Server 2 (for Clock Source is NTP)

Setting	Description	Factory Default
NTP time server	Specify the IP or domain address of the secondary NTP server. The secondary NTP server acts as a backup in case the device fails to connect to the first NTP server.	None

### Time Zone

Setting	Description	Factory Default
Time zone	Select a time zone.	UTC+00:00

### Daylight Saving Time Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Daylight Saving Time.	Disabled

### Offset

Setting	Description	Factory Default
User-specified value	Specify the offset value for Daylight Saving Time.	00:00

### Start

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time begins.	None

### End

Setting	Description	Factory Default
User-specified date	Specify the date that Daylight Saving Time ends.	None

## IP Configuration

### IP Mode

Setting	Description	Factory Default
DHCP	The AWK is assigned an IP address automatically by the network's DHCP server.	Static
Static	Manually configure up the AWK's IP address.	



### IP Address (for Static mode only)

Setting	Description	Factory Default
IP address	Enter the AWK's IP address.	192.168.127.253

### Subnet Mask (for Static mode only)

Setting	Description	Factory Default
Subnet mask	Select the subnet mask. This is used to identify the type of network the AWK is connected to (e.g., 255.255.0.0 for a Class B network, or 255.255.255.0 for a Class C network).	24 (255.255.255.0)

### Default Gateway (for Static mode only)

Setting	Description	Factory Default
IP address	Enter the IP address of the router that connects the LAN to an outside network.	None


### DNS Server 1 and DNS Server 2 (for Static mode only)

Setting	Description	Factory Default
IP address	Enter the primary and secondary DNS server address. After entering the DNS server's IP address, you can input the AWK's URL (e.g., http://ap11.abc.com) in your browser's address field instead of entering the IP address. The Secondary DNS server will be used if the Primary DNS server fails to connect.	None

When finished, click **APPLY**.


## Maintenance and Tools

The user tools and functions are located at the top-right of the interface. Click the three-dot icon in the upper right corner of the page to open the user menu.



## Language

The AWK Series v2.0 firmware and above support language localization. Administrators can select the display language of the web interface from the drop-down menu. The AWK supports the following languages: English, Simplified Chinese, Traditional Chinese, and Japanese. The default is English.




## NOTE

Language options are only available for the web interface. The CLI only supports English.

## Disable Auto Save

**Auto Save** will automatically save the configuration changes to the startup configuration. All parameters will be effective immediately when applied, even if the AWK is restarted. If **Auto Save** is disabled, all parameters will be temporarily stored in the running configuration (memory). To make any changes take effect, you will need to save the running-configuration to the startup configuration after applying the changes.



When **Disable Auto Save** is active, only the running configuration is saved. Disconnecting the power or performing a warm start will undo any running changes. When **Auto Save** is enabled, the startup configurations will be saved on the AWK.

To disable the **Auto Save** function, click **Disable Auto Save** in the menu. When prompted, click **DISABLE** to disable the function.


### Disable Autosave mode

Are you sure you want to disable Autosave mode?

[CANCEL](#) [DISABLE](#)

## Locator

Clicking **Locator** will trigger the wireless and SYSTEM LEDs to start flashing green at a 4 Hz interval for one minute (default) alongside an audible beeper. This feature is useful for locating the physical device in a field site.



### Locator

Stop Mechanism  
Timer

Duration \*  
60

1 - 300 sec.

[CANCEL](#) [START](#)

### Stop Mechanism

Setting	Description	Factory Default
Timer	Use a timer to stop the locator LEDs from blinking.	Timer
Manually	Stop the locator LEDs manually.	

### Duration

Setting	Description	Factory Default
1 to 300 (sec.)	Specify the duration the LEDs will be blinking for.	60


When finished, click **START** to activate the LEDs.

### LEDs triggered: WLAN, SYSTEM




## Reboot

To reboot the AWK, click Reboot.




When prompted, click **REBOOT** to reboot the AWK.




## Reset to Defaults

To reset the AWK to the factory default settings, click **Reset to Defaults**.



When prompted, check **Keep all event logs** if you want to keep the event history, then click **CONFIRM**.



## WARNING


Resetting the AWK to the factory default settings will permanently delete all your configuration settings. This is permanent and cannot be undone.

## Renew Device Unique Key

The AWK Series has a built-in device unique key. This unique key is used to encrypt the following sensitive information stored on the device:

- Configurations
- Certifications
- Encryption/decryption keys (for firmware decryption, diagnostic support encryption, etc.)

To improve device security, administrators can renew the device unique key from the maintenance list.




### WARNING

When triggered, the system will take 12 to 15 seconds to renew the device unique key and will then reboot to activate the renewed device unique key. Please do not power off the device during this process.

## Change Password

Click **Change Password** to change the password of the AWK.



Configure the following settings:

### Change Password

Current Password \* 🗕

---

At least 4 characters 0 / 63

New Password \* 🗕

---

At least 4 characters 0 / 63

Confirm Password \* 🗕

---

At least 4 characters 0 / 63

CANCEL
APPLY

**Current Password**

Setting	Description	Factory Default
4 to 63 characters	Enter the current password.	None

**New Password**

Setting	Description	Factory Default
4 to 63 characters	Enter the new password.	None

**Confirm Password**


Setting	Description	Factory Default
4 to 63 characters	Enter the new password again.	None

When finished, click **APPLY** to change the password.




# Log Out

To log out of the AWK, click **Log out**.



When prompted, click **LOG OUT** to log out of the AWK.



# A. Supporting Information

This chapter presents additional information about this product. You can also learn how to contact Moxa for technical support.

## Device Recovery

In event the device is not working properly, including configuration changes not applying, the first troubleshooting action is to perform a power cycle. This is done by removing and reconnecting the power and verifying if the situation is resolved.

If power cycle does not solve the issue, the next step is to perform a reset to factory default setting. Refer to **Reset Device**.

If you cannot access the web interface, and/or the Reset button is disabled, you can attempt to reset the device via the serial console's CLI FailSafe mode.



### NOTE


The admin password is required to authorize the FailSafe function.

Follow the instructions in the **Accessing the Serial Consoles** section to access the serial console CLI interface and enter the "reload" command to reboot the device.

When the terminal is showing "Restarting device ... [device]# Booting ...", enter the "failsafe" command.


```
COM1,115200,None,8,1,VT100
Profile Edit Port Manager Window Help
Welcome [admin]
The latest successful login time via CLI was: 2021-12-03 11:32:29+00:00
moxa-awk-3252a# reload
Are you sure you want to reboot the device? [y/N]
y
Restarting device ...
moxa-awk-3252a# Booting ...
Not secure ...
failsafe
password:
```

FailSafe mode will be triggered, and you will be prompted to confirm if you want to reset the device back to factory default settings.



```
PCComm Terminal Emulator - COM1,115200,None,8,1,VT100
Profile Edit Port Manager Window Help
COM1,115200,None,8,1,VT100
Welcome [admin]
The latest successful login time via CLI was: 2021-12-03 11:32:29+00:00
moxa-awk-3252a# reload
Are you sure you want to reboot the device? [y/N]
y
Restarting device ...
moxa-awk-3252a# Booting ...
Not secure ...
failsafe
password:
Are you sure you want to reset the device to factory default settings? [y/N]
```

Enter **Y** to make the device initiate a reset to factory default settings.



```
PCComm Terminal Emulator - COM1,115200,None,8,1,VT100
Profile Edit Port Manager Window Help
COM1,115200,None,8,1,VT100
Welcome [admin]
The latest successful login time via CLI was: 2021-12-03 11:32:29+00:00
moxa-awk-3252a# reload
Are you sure you want to reboot the device? [y/N]
y
Restarting device ...
moxa-awk-3252a# Booting ...
Not secure ...
failsafe
password:
Are you sure you want to reset the device to factory default settings? [y/N]Y
reboot
```

When the command line prompt displays the login prompt, it means the device was successfully reset to factory default settings.

# B. Accessing the Serial Consoles

This chapter explains how to access the AWK Series. In addition to HTTP/HTTPS access, the AWK Series can also be accessed through the serial console and Telnet/SSH console. The serial console connection method, which requires a serial cable to connect the AWK Series to a PC's COM port, can be used if you do not know the AWK Series' IP address. The other consoles can be used to access the AWK Series over an Ethernet LAN, or over the Internet.

## RS-232 Console Configuration (115200, None, 8, 1, VT100)

The serial console connection method, which requires a serial cable to connect the AWK Series to a PC's COM port, can be used if you do not know the AWK Series' IP address. It is also convenient to use serial console configurations when you cannot access the AWK Series over Ethernet LAN.



### ATTENTION

Do not use the RS-232 console manager when the AWK Series is powered at reversed voltage (ex. -48 VDC), even though reverse voltage protection is supported.

If you need to connect the RS-232 console at reversed voltage, we highly recommend using an isolator, such as the Moxa TCC-82 isolator.




### NOTE


We recommend using **Moxa PComm (Lite)** Terminal Emulator, which can be downloaded free of charge from Moxa's website.

Before running PComm Terminal Emulator, use an RJ45-to-DB9-F (or RJ45-to-DB25-F) cable to connect the AWK Series' RS-232 console port to your PC's COM port (generally COM1 or COM2, depending on how your system is set up). After installing PComm Terminal Emulator, perform the following steps to access the RS-232 console utility.


1. From Windows desktop, open the Start menu and run **PComm Terminal Emulator** in the PComm (Lite) group.
2. Select **Open** under **Port Manager** to open a new connection.




The **Communication Parameter** page of the Property window opens. Select the appropriate COM port for the Console Connection, **115200** for Baud Rate, **8** for Data Bits, **None** for Parity, and **1** for Stop Bits. Click on the **Terminal** tab and select **VT100 (or ANSI)** for Terminal Type. Click **OK** to continue.



3. The Console login screen will appear. Log into the RS-232 console with the device's account and password.



- The AWK Series device's CLI interface will be displayed. Refer to the device's CLI User's Manual for more information and instructions on how to use the command line interface.



## NOTE

To modify the appearance of the PComm Terminal Emulator window, select **Edit > Font** and then choose the desired formatting options.



## ATTENTION

If you unplug the RS-232 cable or trigger **DTR**, you will be disconnected and logged out for network security reasons. You will need to log in again to resume operations.

# Configuration by Telnet and SSH Consoles

You can use a Telnet or SSH client to access the AWK Series and manage the console over a network. To access the AWK Series' functions over the network from a PC host that is connected to the same LAN as the AWK Series, you need to make sure that the PC host and the AWK Series are on the same logical subnet. To do this, check your PC host's IP address and subnet mask.




## NOTE


The AWK Series' default IP address is **192.168.127.253** and the default subnet mask is **255.255.255.0** (for a Class C network). To configure the AWK Series remotely over a LAN network, set the PC host's IP address to 192.168.127.xxx and subnet mask to 255.255.255.0.

Follow the steps below to access the console utility via Telnet or SSH client:

1. From Windows Desktop, run **Start > Run**, and type *telnet (AWK IP address)* in the Run window and click **OK**. The AWK's default IP address is 192.168.127.253.



2. When using an SSH client (e.g. PuTTY), run the software and enter the AWK device's IP address as the Host Name along with port **22**, and select **SSH** as the connection type.



3. The Console login screen will appear. Please refer to the previous paragraph "RS-232 Console Configuration" and for login and administration.


# C. Security Guidelines

This appendix provides security practices for installing, operating, maintaining, and decommissioning the device. Moxa strongly recommends that our customers follow these guidelines to enhance network and equipment security.

## Installation

### Physical Installation

1. To comply with IEC 62443 requirements, the AWK Series device **MUST** be installed within an access-controlled area, where only authorized personnel have physical access to the AWK Series device.
2. To comply with IEC 62443 requirements, the device **MUST NOT** be directly connected to the Internet, which means the AWK Series device **MUST** be installed within a security perimeter with firewall. Additionally, the various application service servers such as DHCP, NTP, RADIUS, ... etc. shall be securely configured with proper authentication within the security perimeter with firewall protection as illustrated in the image below:



3. Always configure the AWK Series device to comply with your organization's network and security requirements before physical installation. Do not physically install devices that are unconfigured or have an unknown configuration state to avoid unnecessary risks. Please follow the instructions in the Quick Installation Guide, which is included in the package, to ensure you install the device correctly in your environment.
4. The AWK Series has anti-tamper labels visible on the enclosures covering assembly screws. Any tampering to open the mechanical enclosure to access electrical circuit boards will result in the fracturing of anti-tamper labels. This allows an administrator to immediately tell if the device's hardware integrity has been compromised.
5. Ports that are not in use should be deactivated. Please refer to [Hardware Interface](#) and [Ports](#) to review the status of each I/O port and disable any unused ports.
6. The AWK Series devices are industrial WLAN infrastructure components serving as the underlying fabric to support automation processes. These devices are not an integral part of process automation logic and therefore do not support nor are they suitable for any deterministic process control outputs.



# Account Management

Follow these best practices when setting up an account:

1. Each account should be assigned the correct privileges: Only allow the minimum number of people to have admin privilege so they can perform device configuration or modifications, while other users should only have the minimum required access privilege needed to fulfill their corresponding role. The AWK Series supports both local account authentication and remote centralized authentication mechanisms such as RADIUS.
2. Password protection has two means of enforcement: Password Lifetime and Password Complexity. We recommend to:
  - a. Review whether the password lifetime needs to be adjusted according to your organization's policies.
  - b. Review whether the configured password complexity options enabled on the AWK Series system (refer to [Create a New Account](#)) is sufficient according to your organization's policies. If not, modify the password complexity requirements to meet your organization's security guidelines.
3. Enforce regulations that ensure only trusted hosts can access the device. Refer to the [Trusted Access](#) section for more information and instructions.

# Vulnerable Protocols

1. For network security reasons, we strongly recommend that you change the default port numbers, such as the TCP port number for HTTP, HTTPS, Telnet, and SSH, for protocols that are in use. Ports that are not in use but are still accessible, pose a security risk and should be disabled. Refer to the [Management Interface](#) section for more information and instructions.

Below is the list of default port numbers for each protocol used by all external interfaces.

Browser	Protocol Type	Default Port
TCP	HTTP	80
	HTTPS	443
	Telnet	23
	SSH	22
UDP	SNMP	161
	Moxa Service	40404

2. In order to avoid malicious actors from snooping confidential information, users should always apply encryption-based communication protocols such as HTTPS instead of HTTP, SSH instead of Telnet, SFTP instead of TFTP, SNMPv3 instead of SNMPv1/v2c etc. In addition, the maximum number of sessions should be kept to an absolute minimum. Refer to the [Management Interface](#) section for more information and instructions.
3. Users should generate the SSL certificate for the device before commissioning HTTPS or SSH applications. Please refer to the [Certificate Management](#) section for more information and instructions.
4. The HTTP, SNMPv1v2, and Telnet protocols are insecure and by default DISABLED. We recommend to always use secure alternatives such as HTTPS, SNMPv3, or SSL to protect your communications. If insecure protocols need to be used with legacy devices, please consult a qualified security expert to evaluate and implement additional protection measures to prevent any potential security risks.
5. In order to ensure that the device configurations are adequately protected prior to deployment, it is recommended to review the security status of the device. Refer to the [Security Status](#) section for an overview of the device's current security conditions. If any of the identified risks require mitigating action, navigate to the corresponding setup page to address the issue, or consult a qualified security expert to evaluate and implement additional protection measures to prevent any potential security risks.

# Operation

1. For security reasons, The AWK Series does not support TLS v1.0/ v1.1. The AWK Series supports the TLS v1.2 cryptographic algorithm to protect your HTTPS/SSH applications. Please ensure that your web

browser is updated to a version that supports TLS v1.2:

Browser	Version
Microsoft Edge	All versions
Mozilla Firefox	V11 and above
Chrome	V38 and above
Apple Safari	V7 and above for OS X 10,9 (Mavericks) and above

Reference: <https://support.globalsign.com/ssl/general-ssl/tls-protocol-compatibility#Browsers>.

2. The device supports event logs and syslog for SIEM integration:
  - a. Event log: Due to limited storage capacity, the event log can only accommodate a maximum of 10,000 entries. Administrators can set a warning for a pre-defined threshold. We recommend that users regularly back up system event logs. Please refer to the [Event Log](#) section for more information and instructions.
  - b. Syslog: The device supports syslog and advanced secure TLS-based syslog for centralized SIEM integration. Please refer to the [Syslog](#) section for more information and instructions.
3. The device can provide information for control system inventory:
  - a. SNMPv1, v2c, v3: We recommend administrators use SNMPv3 with authentication and encryption to manage the network. Please refer to the MIB file for the detailed OID structure.
  - b. Telnet/SSH: We recommend that administrators use SSH with authentication and encryption to retrieve device properties.
  - c. HTTP/HTTPS: We recommend that administrators use HTTPS with an internally renewed certificate or imported certificate that has been issued by a Certificate Authority (CA) to configure the device.
4. Denial of Service protection: We recommend enabling Trusted Access, Wi-Fi ACL, L2/L3 firewalls to mitigate the risk of DoS attack attempts.
5. Periodically regenerate the SSH and SSL certificates: Even though the device supports up-to-date cipher suites to ensure sufficient complexity, we strongly recommend users to frequently renew their SSH key and SSL certificate in case the key is compromised. Please refer to the [Certificate Management](#) section for more information and instructions.

## Maintenance

1. Perform firmware upgrades frequently to enhance features, deploy security patches, or fix bugs. Periodically check the official product website or Moxa security advisory updates at <https://www.moxa.com/en/support/product-support/security-advisory/security-advisories-all>.
2. Periodically, or after each maintenance session, back up the running system configuration to be able to restore the device back to the latest stable, secure state if necessary. The device supports password encryption and signature authentication for backup files to protect the system configuration files from being tampered with,
3. Examine event logs frequently to detect any anomalies.
4. Periodically, or after each maintenance session, check the [Security Status](#) overview to review and confirm the current device's security conditions.
5. To report vulnerabilities of Moxa products, please submit your findings on the following web page: <https://www.moxa.com/en/support/product-support/security-advisory/report-a-vulnerability>.

## Decommission

1. Power off the device to be decommissioned and dismount it from its physical installation location.
2. Identify the serial number or device name and locate (if applicable) any configuration backup files or certificates generated by the device to be decommissioned and ensure the deletion of these files.
3. To avoid any sensitive information such as the organization's information, account passwords, or certificates from being leaked, always reset the device to the factory default settings before decommissioning the device.

## D. Service Authority Table

This appendix lists the required authority for each feature or service. The purpose of this table is to help administrators review and decide the appropriate account privileges and role to assign to user accounts.

Authority	Admin	Engineer	User
Account System	Yes	No	No
Auditor System	Yes	Yes	No
Advanced Diagnostics	Yes	Yes	No
Diagnostics	Yes	Yes	Yes
Network Configuration	Yes	Yes	No
Status Monitoring	Yes	Yes	Yes
System Backup	Yes	No	No
System Management	Yes	Yes	No

Configuration Section	Authority Required
Device Summary	Status Monitoring
<b>System</b>	
<b>System Management</b>	
System Information	System Management
Firmware Upgrade	System Management
Configuration Backup and Restore	System Backup
<b>Account Management</b>	
User Account	(Refer to breakdown below)
Settings	Account System
Session Management	System Management
Password Policy	Account System
<b>Management Interface</b>	
User Interface	System Management
Hardware Interface	System Management
SNMP	(Refer to breakdown below)
SNMP	System Management
SNMP Account List	Account System
<b>Time</b>	
System Time	System Management
<b>Wi-Fi</b>	
Wireless Settings	(Refer to breakdown below)
General	Network
MAC Cloning	Network
Status	Status Monitoring
Connection Management	Network
Roaming	Network
Wi-Fi Security	Network
<b>Ports</b>	
Port Settings	(Refer to breakdown below)
General	Network
Port Status	Status Monitoring
<b>Layer 2 Switching</b>	
VLAN	Network
<b>IP Configuration</b>	
General	System Management
Status	Status Monitoring
<b>Network Service</b>	
DHCP Server	Network

Configuration Section	Authority Required
<b>Routing and Nat</b>	
<b>Routing</b>	
<b>Unicast Route</b>	
Static Route	Network
Routing Table	Status Monitoring
<b>NAT</b>	
Rule List	Network
<b>Firewall</b>	
Layer 2 Policy	Network
Layer 3 Policy	Network
Certificate Management	System Management, Auditor System, System Backup, Status Monitoring, Diagnostics, Advanced Diagnostic, or Network Configuration
<b>Security</b>	
<b>Device Security</b>	
Login Policy	System Management
Trusted Access	System Management
<b>Diagnostics</b>	
Security Status	Status Monitoring
<b>Network Status</b>	
Network Statistics	Status Monitoring
LLDP	(Refer to breakdown below)
Settings	Network
Status	Status Monitoring
Bridge Table	Status Monitoring
ARP Table	Status Monitoring
<b>Event Logs and Notifications</b>	
Event Log	(Refer to breakdown below)
Log List	Status Monitoring
Registered Logs	Auditor System
Oversize Action	Auditor System
Backup	Status Monitoring
Event Notifications	Auditor System
Syslog	Auditor System
General	Auditor System
Authentication	Auditor System
SNMP Trap/Inform	Auditor System
General	Auditor System
SNMP Trap/Inform Account	Auditor System
Email Settings	Auditor System
General	Auditor System
Authentication	Auditor System
Relay Alarm Cut-off	Auditor System
<b>Tools</b>	
<b>Wi-Fi Tools</b>	
Channel Scan	Advanced Diagnostic
Wi-Fi Mirroring	Diagnostic
General	Diagnostic
Authentication	Diagnostic
RSSI Reporting	Diagnostic
System Data Collection	Diagnostic
Diagnostic Support	Advanced Diagnostic
Ping	Diagnostic
Setup Wizard	Network and System Management
<b>Maintenance Bar</b>	
Language	Basic
Disable/Disable Auto Save	System Management
Locator	Diagnostic

<b>Configuration Section</b>	<b>Authority Required</b>
Reboot	System Management
Reset Device	System Management
Renew Device Unique Key	System Management
Change Password	Basic
Log Out	Basic